

# User Manual NAMES 3.0

Doc-IDDB.NAMESMAN30.NTVersion1.1As of05.05.2017StateFinal VersionSubject to change without notice

Copyright 2017 NovaTec Kommunikationstechnik GmbH

Forwarding, duplication, utilisation, saving or publication of this document or its contents are neither allowed in excerpts nor completely, unless explicitly permitted in written form.

Infringement obliges to payment of damages. All rights reserved.



# **CONTENT**

1	Introduction	6
2	System requirements	7
2.1	NAMES execution environment	7
2.1.1 2 1 2	Minimum specifications	7 7
2.2.2	Database server	7
2.2	Compatible NovaTec products	,
2.5	Compatible Nova et products	
2.4	Natural and Energian	8
2.5	Network configuration	8 
3		9
3.1	Running the installer	9
3.2	Licence installation	13
3.3	Database initialisation	15
3.4	Uninstalling	16
4	Configuration	
4.1	NAMES configuration file	18
4.1.1	Database configuration	18
4.1.1.1	Oracle DB 11g	
412	Web server configuration	10 19
4.1.2.1 4.1.2.2	Changing the listen port Using secure mode (HTTPS)	19 19 19
4.1.3	Miscellaneous configuration	20
4.1.3.1	Storage path	20
4.1.3.3	Target monitoring alert time	20
4.2	Logging configuration file	20
4.3	Firewall settings	21
5	Administration	22
5.1	Starting NAMES	22
5.2	First login	22
5.3	General settings	23
5.3.1	Maximum number of simultaneous jobs	23
5.3.2	Maximum number of simultaneous logins	23
5.3.3	Maximum number of simultaneous reconfigurations	23
5.3.4	Keep CDRs	24
5.3.5	Keep log entries	24
5.4	User management	25
5.4.1	Users	25
DB.NAMESM	IAN30.NT As of May 5th, 2016	2/137



5.4.1.1 5.4.1.2 5.4.1.3	Creating a user Editing a user Disabling/Enabling a user	25 26 27
5.4.2 5.4.2.1 5.4.2.2 5.4.2.3	User groups Creating a user group Editing a user group Deleting a user group	27 27 28 28
5.5	Role management	29
5.5.1	Creating a role	29
5.5.2	Assigning permissions to a role	30
5.5.3	Deleting a role	30
5.6	SNMP configuration	30
5.7	Certificate Authority configuration	31
5.7.1	General configuration procedure	32
5.7.2	Configuring NAMES as a Root CA	34
5.7.3	Configuring NAMES as a subordinate CA	35
5.7.4	Configuring NAMES using an existing key and certificate	36
5.8	SSL contexts	36
5.8.1	Creating an SSL context	37
5.8.2	Editing an SSL context	37
5.8.2.1	Adding a private key and certificate	37 38
5.8.2.3	Adding a trusted certificate authority	38
5.8.2.4	Removing a trusted certificate authority	39
5.8.3	Setting an SSL context as default context	39
5.8.4	Removing an SSL context	39
5.9	Managing firmware images, music on hold files and Licence Manager	39
5.9.1	Firmware images	39
5.9.2	Music on Hold	40
5.9.3	Licence Manager	42
5.10	Shutting NAMES down	43
6	Usage	44
6.1	Provisioning	44
6.2	Configuring the system	47
6.2.1	System Settings	49
6.2.1.1	System Information	49 40
6.2.1.2	Network	+9 49
6.2.1.2.2	Hostname	51
6.2.1.2.3	Single Port	51 52
6.2.1.2.4	Default Gateway	52
6.2.1.2.6	DNS Servers	52
6.2.1.2.7	VLAN	52 52
6.2.1.4	Time Settings	55 54
	-	

Copyright 2017 NovaTec Kommunikationstechnik GmbH



6.2.1.4.1	Time zone	54
6.2.1.4.2	Daylight Savings Time	54
6.2.1.5	Monitoring	25 
6.2.1.5.1	Parameterless alarms.	5 5
6.2.1.5.2	CPU usage Alarm	56 50
0.2.1.5.3	Call Setup Time Alarm	30
0.2.1.5.4		20
62156	ASP Sottings	50
0.2.1.5.0		57
6.2.2	Hardware	<u>אכ</u>
0.2.2.1	Changing the chaosis time	20
0.2.2.1.1	Changing the chassis type	59 50
6222	Analoguo Profilos	29
6223	VoID Part Profiles	50 51
0.2.2.5		71
6.2.3	Security	22
6.2.4	Telephony	58
6.2.4.1	Localisation	58
6.2.4.2	VoIP	58
6.2.4.2.1	SIP	58
6.2.4.2.1.1.1	ISIP Codec Mapping	58
6.2.4.2.1.2	Global SIP Options	/2
6.2.4.2.1.3	SIP Timeout Options	//
6.2.4.2.1.4	I runks	/9
6.2.4.2.2	NAT	33
0.2.4.2.3		33 34
0.2.4.3		34 57
674.3.1	Call Pouting	27 27
67441		ינ 72
674411	New Trunk Group	ינ 72
6744111	New Number Group	יכ 1
6244112	New Number	34
62442	All subscribers	4
624421	Subscriber aroun	- - - -
6.2.4.4.2.1.1	Creating a Subscriber	
6.2.4.4.2.1.2	2Creating a SIP Subscriber	)2
6.2.4.4.3	Line groups	)7
6.2.4.4.3.1	New Line Group	57
6.2.4.4.4	Adjusting the routing	)9
6.2.4.5	Call Take Over Groups	12
6.2.4.6	Dialling Codes	14
6.2.4.7	Synchronisation11	15
6.2.4.8	Call Data Profiles	16
6.2.4.9	Channel Permissions	18
6.2.4.10	MLPP	18
6.2.4.11	ALCR	19
6.2.4.12	Global Options	20
6.2.4.13	Bank holidays	20
6.2.4.14	Premium Rate Numbers	22
6.2.4.15	Network Service Provider	23
6.2.4.15.1	Network Service Provider	23
6.2.4.15.2	Regional charge categories	25
6.2.4.15.3	I me charge categories	26



6.2.4.15.4 6.2.4.15.5	Assign telephone numbers Call barring	127 128
6.3	Targets	129
6.3.1	Editing a target	129
6.3.2	Removing a target	129
6.3.3	Multiple target actions	129
6.3.4	Target details	130
6.4	Target groups	130
6.4.1	Creating a target group	131
6.4.2	Editing a target group	131
6.4.2.1	Adding Targets	131
6.4.2.2	Removing targets	132
6.4.3	Removing a target group	132
6.5	Jobs	132
6.5.1	Job types	132
6.5.1.1	Upload Firmware	132
6.5.1.2	Reset	132
6.5.1.3	Download Trace Files	133
6.5.1.4	Download Log File	133
6.5.1.5	Download CDRs	133
6.5.1.6	Sign Certificate	133
6.5.2	Job states	133
6.5.3	Creating a job	133
6.5.4	Viewing and modifying scheduled jobs	134
6.5.5	Active jobs	135
6.5.6	Completed and failed jobs	135
6.6	Job Trigger	136
6.6.1	Creating a Job trigger	136
6.6.2	Edit Job triggers	137
6.7	User settings	137



# **1** Introduction

The NovaTec Administration and Management Element Server (NAMES) allows you to manage all your NovaTec devices through a central service. It contains functions to assist you with deployment, maintenance, configuration and monitoring. The following image shows NAMES in a typical deployment:



NAMES can and should be used as the central administrative element for any installation of NovaTec devices. Currently additional tools (the NovaTec Maintenance Package, consisting of the NovaTec Trace Info Client and NovaTec Call Server) are required for certain functionalities and are therefore included in the overview above as installed on the client PCs.

The following documentation applies to the fully licensed version of NAMES. For availability of individual features, please see the terms of your licence. The free version of NAMES does not contain any of the following features:

- Scheduled Jobs,
- Triggered Jobs,
- Certificate Authority functions,
- User/role management (only the default user "names" is available),
- SNMP mapping,

Multi-user capability (only one user session at a time).



# **2** System requirements

## 2.1 NAMES execution environment

NAMES is intended to run on physical or virtual servers under a Windows Server operating system. As NAMES is implemented in Java, a Java Runtime Environment is required.

## 2.1.1 Minimum specifications

At a minimum, the following specifications are necessary to run NAMES:

- 256 MB of free memory,
- 2 CPU cores,
- 256 MB of disk space,
- Windows Server 2008 R2 Standard Edition SP1,
- Oracle Java SE 8 64-bit Runtime Environment, latest update,
- Oracle Java 8 Unlimited Strength Jurisdiction Policy Files.

With these specifications, only a small number of devices (up to about 10) can be administered. A short deletion interval must be used if automatically retrieving CDRs from the devices, as these can quickly fill up hard drive space, depending on the call volume.

### 2.1.2 Recommended specifications

The following specifications are recommended for small to medium installations (up to about 50 devices):

- 512 MB of free memory,
- 4 CPU cores,
- 1 GB of disk space,
- NTP time synchronisation.

Larger installations require additional resources and should be sized according to specific requirements.

## 2.2 Database server

NAMES will use an embedded database by default. However, the use of an external database is possible and may offer advantages with regard to availability and backup planning. NAMES supports the following external databases:

- Oracle DB 11g,
- MySQL 5.5.

If using Oracle, it is recommended to configure a Unicode character set.

## 2.3 Compatible NovaTec products

NAMES must be used in conjunction with specific versions of NovaTec hardware, firmware and PC utilities. Following versions may be used with NAMES 3.0:

- Hardware: CCU4, CCU6
- Firmware: 00.09.00.xx



• NMP 7.4.x only TI-Client, Call-Server and network services

## 2.4 Compatible client software

The NAMES web user interface was tested with Microsoft Internet Explorer 11 and Firefox. The web framework in use claims to support all relevant modern desktop browsers and spot checks have shown no contrary evidence; however, extensive testing has not been done. While NovaTec welcomes bug reports for non-Microsoft browsers, fixes will at best be provided on a best-effort basis and support may be unavailable.

## 2.5 Network configuration

NAMES makes extensive use of network communication. This means, that for correct operation, the required connections must be able to be established, and bandwidth may become a limitation, especially in installations with many devices.

All ports can be configured freely, however it is generally recommended to use the default ports, if possible. For details about default port numbers and connections, please see the document "IP Port Matrix" available from the download section of our homepage (http://www.novatec.de/cms/en/Downloads/Downloadarea.html).



# **3** Installation

## 3.1 Running the installer

To install NAMES begin by running the provided installer file. The following dialogue box appears:



After selecting "Next" choose the installation folder for NAMES.

🗑 NAMES 3.0.0 Setup	_ 🗆 X
<b>Choose Install Location</b> Choose the folder in which to install NAMES 3.0.0.	
Setup will install NAMES 3.0.0 in the following folder. To install in a different folder, click Browse and select another folder. Click Next to continue.	
Program Files (static)	
C:\Program Files\NovaTec\NAMES Browse	
Space required: 73.3MB	
Space available: 14.0GB	
Nullsoft Install System v3.01	
< <u>B</u> ack <u>N</u> ext > Ca	ncel

Files that normally don't change during the operation of NAMES are placed into the installation folder, like executables, libraries, resources and configuration files. Files that may change during operation, like the embedded database files and logs, are placed in the data folder, which can be configured on the next page:

User Manual NAMES 3.0

Version 1.1 (final Version)



🗊 NAMES 3.0.0 Setup	
Choose Data Location Choose the folder in which data files will be kept, including the database files if using the embedded database.	
Setup will install data files in the following folder and configure NAMES appropriately. To different folder, click Browse and select another folder. Click Next to continue.	) use a
Data Files (changed at runtime)    C:\ProgramData\NovaTec\NAMES   Browse  Browse	
Space required: 73.3MB Space available: 14.0GB	
Nullsoft Install System v3;01	ancel

After configuring the folders for program and data files, you choose the start menu folder:

🗊 NAMES 3.0.0 Setup	. 🗆 🗙
Choose Start Menu Folder Choose a Start Menu folder for the NAMES 3.0.0 shortcuts.	()
Select the Start Menu folder in which you would like to create the program's shortcuts. Yo can also enter a name to create a new folder.	
NovaTec\NAMES	
Accessories Administrative Tools Java Maintenance Startup	
Nullsoft Install System v3.01	cel

This is the final step before the installation starts, so ensure all settings are correct before clicking "Install". The installer will proceed to complete the necessary installation steps, including installation of a Microsoft Visual C++ Redistributable and the licencing files, including an evaluation licence.



NAMES 3.0.0 Setup	
Installing Please wait while NAMES 3.0.0 is being installed.	
Extract: TargetGroupViewer\$DeleteMenuListener\$1.class	
Show details	
Nullsoft Install System v3.01	Next > Cancel

The installation of the licencing mechanism will require a separate acknowledgement:

After clicking "OK" the installation will complete.

User Manual NAMES 3.0

Version 1.1 (final Version)



🗊 NAMES 3.0.0 Setup		1		
Installation Complete Setup was completed successfully.				
Completed				
Show <u>d</u> etails				
Nullsoft Install System v3,01	Capital L			
		Clicking "Next" ta	kes you to the final	screen of

the installer that describes which steps need to be taken next.







If you wish to use the embedded database and do not want to use HTTPS to access the web UI, NAMES is ready to use. You can manually start the service from the Windows service management UI (see section 5.1) or restart the system. After every system restart, NAMES will start automatically.

# 3.2 Licence installation

NAMES is installed with a 60-day evaluation licence. Apart from the limited evaluation period, this licence also contains other limitations, such as the number of devices that can be managed. For production use, a perpetual licence has to be installed.

The licencing system in use requires the user to use a licencing tool to collect certain system information into a file, which must then be sent to NovaTec e.g. via email. The information contained in the file is used to create an individualised licence, which is sent back to the client who then has to install it using the same tool.

The process is as follows:

- 1. Run the application "NAMES License Tool" in the NAMES installation folder. A window with two tabs will appear. The first tab, which is selected by default, allows you to collect the licence information.
- 2. Click the Collect Information button and then select a location and name for the generated system information file. The tool will inform you that the key status was successfully retrieved:

NovaTec

🥙 Sentinel HASP RUS	_ <b>D</b> _ X
Collect Key Status Information Apply License Update	•
Key status retrieved from HASP successfully.	
Collect Information	

- **3.** Send the generated file (e.g. info.c2v) to your sales contact at NovaTec with the order number for your NAMES licence purchase. If you have not purchased a NAMES licence yet, contact a sales representative for licensing terms.
- **4.** NovaTec will generate a licence file (e.g. customer.v2c) and return it to you.
- **5.** Run the "NAMES License Tool" again. This time, select the second tab which allows you to apply the licence file:



Collect Key Status Information	Apply License Update	
Update File		
•		

- **6.** Click the button. A file selection dialogue will open, allowing you to select the file with the licence information sent to you by NovaTec.
- **7.** Finally, click the Apply Update button. The licence is now installed and ready to be used. If NAMES is running, restart NAMES to load the new licence information.

# 3.3 Database initialisation

If using an external database, the database structure (tables and some basic database rows) must be imported. If using the embedded database, this step is not required, as the installed database comes prepared with this structure.

The NAMES installation folder contains two SQL scripts for the two supported external database systems. Select the file appropriate to the database in use (either names-oracle.sql for Oracle DB 11g or names-mysql.sql for MySQL 5.5) and import it into the schema (Oracle) or database (MySQL) that you wish to use for NAMES.

For security reasons, it is recommended to use a separate database user for NAMES. This database user should have all permissions on the corresponding schema/database, except table create/drop privileges, as these are not required for normal operation. Database import operations, and later database upgrades, where necessary when upgrading NAMES, can be carried out with a privileged user that can create, alter and drop tables.

After setting up the database, the correct connection information must be provided to NAMES. See section 4.1.1 for further information about configuring NAMES database connectivity.

User Manual NAMES 3.0

Version 1.1 (final Version)



# 3.4 Uninstalling

If required, NAMES can be uninstalled by selecting the "Uninstall" option from the "Start Menu" folder selected or created during installation (default: NovaTec\NAMES). After starting the uninstaller, you are first prompted to confirm that you really wish to uninstall NAMES:



After selecting "Yes", the uninstaller will ask you whether you also wish to remove the data folder, which contains logs, templates and the embedded database, which, if in use, will contain all NAMES runtime data such as configured targets, system configurations etc.. These files will be irrevocably deleted if you select "Yes", so ensure that you have made a backup of these files if you wish to have access to the data at a later point of time:



The uninstaller also reminds you that, should you be using an external database, you will need to drop any data from this database manually. The uninstaller will then proceed to remove the installed files, services, registry settings and shortcuts from the system. Should any files remain in the installation folder (user created files such as Java key stores, backup copies of configuration files etc.) after the uninstallation is completed, the uninstaller will list them and ask you whether you want these files to be removed as well.

After successfully removing NAMES from the system, the uninstaller will show a confirmation screen:





The uninstallation has now been completed.



# 4 Configuration

# 4.1 NAMES configuration file

The main configuration file for NAMES is the file names.properties in the installation folder (default: C:\Program Files\NovaTec\NAMES). This file contains configuration settings for the NAMES database, for the embedded web server and for the Java Runtime Environment, as well as some other important start up settings.

The configuration file contains extensive commentary, including the default settings for each setting.

## 4.1.1 Database configuration

If using the embedded database (the default), no further configuration is necessary. To switch back to the embedded database after using an external database, simply comment out all the database configuration directives by prefixing them with a hash mark (#).

To use an external database, the correct connection settings for the database in use must be made. To do this, uncomment the corresponding lines and replace the default setting with the setting you want to change it to.

#### 4.1.1.1 Oracle DB 11g

To configure the Oracle DB 11g connection, make the following configuration settings:

```
database_type = oracle
database_url = jdbc:oracle:thin:@<Hostname/Address>:<Port>:<System Identifier>
database_username = <Username>
database_password = <Password>
database_schema = <Schema>
```

Replace the placeholder text in above example with the corresponding information for your Oracle database. For example, if you are running a database on the server with the hostname oracle on the port 1521 with the System Identifier (SID) ORCL, and you have prepared a user with the name names and password secret, using their own schema, configuration should be as follows:

```
database_type = oracle
database_url = jdbc:oracle:thin:@oracle:1521:ORCL
database_username = names
database_password = secret
database_schema = NAMES
```

NAMES will automatically transform the schema name into uppercase internally, as required by Oracle DB 11g. You may therefore also enter the schema name in lowercase, however entering it in uppercase is recommended for consistency.

### 4.1.1.2 MySQL 5.5

To configure the MySQL 5.5 connection, make the following configuration settings:

```
database_type = mysql
database_url = jdbc:mysql://<Hostname/Address>:<Port>/<Database>
database_username = <Username>
```

As of May 5th, 2016

User Manual NAMES 3.0

Version 1.1 (final Version)



```
database_password = <Password>
database_schema = <Database>
```

Replace the placeholder text in above example with the corresponding information for your MySQL database. Please note that MySQL uses the terms "database" and "schema" interchangeably. For example, if you are running a database on the server with the hostname mysql on the port 3306, have created a database with the name namesdb and prepared a user with name names and password secret and read/write access to this database, configuration should be as follows:

```
database_type = mysql
database_url = jdbc:mysql://mysql:3306/namesdb
database_username = names
database_password = secret
database_schema = namesdb
```

### 4.1.2 Web server configuration

The embedded web server need not be configured if you wish to run it in the default unsecured HTTP mode on the default port of 80. If you wish to enable HTTPS or use a non-standard port, you have to configure the webserver.

#### 4.1.2.1 Changing the listen port

If you simply wish to change the port used for incoming connections from the default 80, make the following setting:

```
webserver.port = <Port>
```

Replace <Port> with the port number you wish to use. Setting the port to 0 will cause NAMES to use the default port, depending on whether HTTPS is configured or not.

NAMES will listen on all available network interfaces.

#### 4.1.2.2 Using secure mode (HTTPS)

In order to secure the web UI of NAMES, you must first generate a pair of keys and acquire a certificate for your webserver. The key and certificate must then be placed in a Java key store with the name keystore.jks, while the root certificate of the issuing PKI as well as any other trusted root certificates must be placed in a key store with the name truststore.jks in the NAMES installation folder.

How to generate the key and acquire the certificates depends on your PKI and security policies and is beyond the scope of this document. If in doubt, please consult with your resident security expert.

The key stores may be created and populated with any appropriate tool, including the Java key tool contained in the standard JRE distribution and graphical tools such as the free KeyStore Explorer. When importing the private key, ensure that the password for the key and the key store password are identical and that only one key and certificate pair is contained in the key store.

Once the keystore.jks files have been placed in the installation folder make the following settings:

```
webserver.secure = 1
```

webserver.keystore\_password = <keystore.jks Password>

The NAMES web server will now run on port 443 by default, which is the well-known port for HTTPS. If you wish to use a non-standard port instead, configure a different port as described above.



## 4.1.3 Miscellaneous configuration

#### 4.1.3.1 Storage path

The storage path is the path to the data folder. During installation, this is automatically set to the path you selected; changing this is only necessary if you decide to move your data folder. To move your data folder, stop the NAMES service, move the data folder to its new location, set the storage\_path setting to the new location and restart NAMES.

#### 4.1.3.2 Maximum Java heap size

Depending on the size of your installation and how you use NAMES, a large amount of memory may be required. By default, the maximum heap size of NAMES is limited to 512 MB, which is sufficient for most small to medium installations, but may cause out-of-memory conditions for certain memory-intensive operations (mainly XML imports with embedded base64-encoded binaries such as configurations, firmware etc.).

To allow NAMES to use more memory, change the memsize setting. For example, to allow NAMES to use up to 1GB of Java heap memory, make the following setting:

memsize = 1G

Note that the actual Java process size will exceed the configured limit, as memory for other parts of the Java virtual machine is also needed; the heap size is the main determining factor for the Java process size. NAMES will normally start with a lower process size, but will grow, possibly up to the limit, during use.

#### 4.1.3.3 Target monitoring alert time

NAMES monitors the target systems using regular time events sent by the systems. You can configure how many time events a system is allowed to miss before it is considered offline and a SNMP trap is generated. It is recommended to set this to two or even three, as time events may be delayed on occasion. To configure the maximum number of missed time events, make the following setting:

max\_missed\_timeevents = <Number of Max Missed Time Events>

# 4.2 Logging configuration file

Configuration for the logging system (log4j) is stored in the file log4j.properties. The settings in this file apply to the NAMES error and debugging log as well as the accounting log. It is possible to configure log levels for various NAMES components as well as which appenders (log sinks; anything from a simple file appender through to a remote logging server) these logs should be sent to.

In default post-installation configuration, all modules are set to log level "WARN" and full accounting logs are active. The log files names-log4j.log and accounting.log in the subfolder log of the NAMES data folder, as chosen during installation, are used as output.

For more complex configurations, please refer to log4j documentation or consult with NovaTec.

**Warning**: Setting some modules to DEBUG or even TRACE log levels will produce very large amounts of log information which may slow execution speed to a point where normal operation is not possible. These log levels should only be set if requested by a NovaTec service technician for troubleshooting purposes.



# 4.3 Firewall settings

If using a firewall on the host on which NAMES is installed (the Windows Firewall is enabled by default) or on another system between the NAMES server and the client PCs, a firewall exception has to be configured. At the least, an exception allowing incoming connections to the configured NAMES web UI port (80 by default) has to be present. Additional firewall exceptions are required for incoming connections to configured CallHome Servers (see section **Fehler! Verweisquelle konnte nicht gefunden werden.**).

It might also be necessary to configure firewall exceptions for connections originating from NAMES and going to the target devices.

How these exceptions are configured depends on the firewall product(s) you are using and the structure of your network; further explanation is beyond the scope of this document. For default port numbers, please refer to the document "IP Port Matrix", which is available on NovaTec's website under download/handbooks (<u>http://www.novatec.de/cms/en/Downloads/Downloadarea.html</u>).



# **5** Administration

# 5.1 Starting NAMES

NAMES is installed as a service. This means that it is not started like a normal application, but is managed by the system. During installation, NAMES is configured to run automatically at system start-up, so you will normally not need to explicitly start NAMES. However, if you have just installed NAMES and a condition occurs which prevents NAMES from running (such as the database being unavailable) or you manually shut NAMES down, you will have to start NAMES manually.

To do this, you should generally use the Server Manager UI, where you can find the item "Services" under "Configuration":

🖡 Server Manager							
File Action View Help							
🗢 🔿 🗾 🖬 🖬 🙆 🐱							
Server Manager (VM1-2)	Services						Actions
Roles	Q. Services						Services
Diagnostics						–	More Actions
Configuration	NAMES	Name 🔺	Description	Status	Startup Type	Log On As 📃 🔺	
🛨 🕑 Task Scheduler		NAMES	NovaTec A		Automatic	Local System	NAMES 🔺
🛨 🔬 Windows Firewall with Adva	Start the service	🗛 Netlogon	Maintains a		Manual	Local System	More Actions
🔍 Services		Network Access Pr	The Netwo		Manual	Network S	
i WMI Control	Description:	Setwork Connections	Manages o	Started	Manual	Local System	
🛨 🎊 Local Users and Groups	NovaTec Administration and Management	Service Network List Service	Identifies t	Started	Manual	Local Service	
🛨 🚟 Storage	Liements Server	Network Location A	Collects an	Started	Automatic	Network S	
		Network Store Inte	This servic	Started	Automatic	Local Service	
		OracleMTSRecover			Manual	Local System	
		Reformance Count	Enables re		Manual	Local Service	
		Reformance Logs	Performan		Manual	Local Service	
		🔍 Plug and Play	Enables a c	Started	Automatic	Local System	
		🗛 PnP-X IP Bus Enum	The PnP-X		Disabled	Local System	
		🖓 Portable Device En	Enforces g		Manual	Local System	
		Power	Manages p	Started	Automatic	Local System	
		Rrint Spooler	Loads files	Started	Automatic	Local System	
		Reports an	This servic		Manual	Local System	
		Notected Storage	Provides pr		Manual	Local System	
		Remote Access Aut	Creates a		Manual	Local System	
		Remote Access Co	Manages di		Manual	Local System	
		🧟 Remote Desktop C	Remote De	Started	Manual	Local System	
		Remote Desktop Se	Allows user	Started	Manual	Network S	
		Remote Desktop Se	Allows the	Started	Manual	Local System	
		Remote Procedure	The RPCSS	Started	Automatic	Network S	
		Remote Procedure	In Window		Manual	Network S	
		Remote Registry	Enables re	Started	Automatic	Local Service	
		Resultant Set of Po	Provides a		Manual	Local System	
		Routing and Remot	Offers rout		Disabled	Local System	
		RPC Endpoint Mapper	Resolves R	Started	Automatic	Network S	
		Secondary Logon	Enables st		Manual	Local System	
		Secure Socket Tun	Provides s		Manual	Local Service	
		Security Accounts	The startu	Started	Automatic	Local System	
		Sentinel Local Licen	Manages li	Started	Automatic	Local System 👻	11
<b>↓</b>	Extended Standard						

Select the NAMES service from the list and click the "Start" link. Please note that, though the start-up progress window appears only briefly, at that point of time only the Java Virtual Machine has been started, the start-up process of the actual application is still ongoing. It will take a little longer – up to a minute or two – until the NAMES web UI is available.

# 5.2 First login

To log in to the NAMES web GUI open your browser and navigate to the address where NAMES is installed. You will be asked for your login data:

Copyright 2017 NovaTec Kommunikationstechnik GmbH

User Manual NAMES 3.0



Name	names	
Password	•••••	
	Login	

After database installation, a single administrative user with name names and password names is present. Use this login data when logging in to NAMES for the first time.

After logging in, it is recommended to immediately change the names user's password as described in section 6.7 below.

## **5.3 General settings**

In the "General Settings" dialogue, you can set a number of miscellaneous parameters:

General Settings			$\otimes$
Maximum number of simultaneous jobs	10		
Maximum number of simultaneous logins	30		
Maximum number of simultaneous reconfigurations	20		
Keep CDRs (days)	0	* *	
Keep Log Entries (days)	0	- <b>A</b>	
Ok Abbrech	en		

#### 5.3.1 Maximum number of simultaneous jobs

This setting specifies how many jobs NAMES may run at the same time. The maximum setting is currently limited to ten simultaneous jobs. You may wish to reduce this if bandwidth limitations lead to poor performance or you want to reduce NAMES bandwidth usage.

### 5.3.2 Maximum number of simultaneous logins

This setting specifies how many users may use the NAMES web UI at the same time. The default is 30 (the maximum setting available), but it can be reduced if server performance is not sufficient with that number of simultaneous users.

### 5.3.3 Maximum number of simultaneous reconfigurations

This setting refers to the reconfiguration feature of NAMES, which allows other applications to use NAMES' SOAP interface to reconfigure specific settings on a target. Full documentation on this feature is available on request.

```
DB.NAMESMAN30.NT
```



## 5.3.4 Keep CDRs

This setting controls how long CDRs are kept before being automatically deleted from the database. The default setting is 0, which means "never delete CDRs". If you are regularly downloading CDRs from your systems, especially if using automated CDR downloads, it is recommended to ensure that CDRs are regularly removed from the database. This may be accomplished through an external mechanism, e.g. if you wish to archive old CDRs, or through NAMES' automated deletion system.

If this setting is set to any number larger than 0, NAMES will regularly delete any CDRs that are older than this number of days.

## 5.3.5 Keep log entries

This setting is the equivalent to "Keep CDRs", except it applies to system logs which have been downloaded from the targets. These logs are saved in the NAMES database and, similarly to CDRs, will need to be deleted on occasion. The default setting is also 0.

User Manual NAMES 3.0

Version 1.1 (final Version)



## 5.4 User management

NAMES has an integrated user management system, which is the base for the AAA (authentication, authorisation and accounting) system. You can create users, assign them to groups, assign roles (more on roles in section 5.5) to users or groups and disable users. Users cannot be deleted or renamed, as this can lead to ambiguity or lack of traceability in the accounting logs.

The paid version of NAMES 3.0 allows the creation of multiple users and user groups. In the free version of NAMES 3.0 only the default admin user "names" is available.

Jser	Managen	nent	
User	rs User	Groups	
٩		í.	
	Active	Name	
2		names	

The User Management UI is available from the maintenance menu:

## 5.4.1 Users

#### 5.4.1.1 Creating a user

To create a user, right-click in the user table to bring up the context menu, and select ". The user creation dialogue is displayed:



Create User			X
			Ŭ
Name	User1		Roles
Password	••••		Administrator
Confirm	••••		User
Icon Theme	Standard	*	
Activation	active	•	
	Ok		Cancel

Some changes may require a re-login for activation.

You must enter a user name and initial password for the new user. You can also explicitly assign a role to the user at this stage, though this is not required. Changing the "Activation" setting allows you to create users that are disabled, for example to reserve a certain user name.

#### 5.4.1.2 Editing a user

To edit a user, right-click the user in the User Management UI and select "Edit" from the context menu. The user edit dialogue is displayed:

Edit User			6	9
Name Password	User1		Roles	
Confirm			User	
Icon Theme	Standard	-		
Activation	active	*		
[	Ok		Cancel	

#### Some changes may require a re-login for activation.

The user edit dialogue allows an administrator to change all the settings that were previously set in the user creation dialogue. To change a user's password, the checkbox next to the password entry field must be checked. Typing into the password field will automatically check the box. For security reasons, the password field will always be blank when the dialogue loads.

User Manual NAMES 3.0

Version 1.1 (final Version)



#### 5.4.1.3 **Disabling/Enabling a user**

Users may be disabled and will then no longer be able to log in to NAMES. This is achieved by editing the user (see 5.4.1.2) and setting the activation status to "inactive". To re-enable the user, set the activation status back to "active".

#### 5.4.2 User groups

User groups are an entirely optional element of user management. If you wish, you can assign your users to certain user groups. Users will inherit any roles assigned to their groups.

User groups are managed through the User Management UI, which is opened by clicking on "User Management" in the "Maintenance" menu. Switching to the second tab in the User Management UI displays the User Group UI:



#### 5.4.2.1 Creating a user group

To create a user group, right-click in the user group table and select "Create". The group creation dialogue is displayed:



Create	UserGroup			$\otimes$
Name	Group 1			
	Members		Roles	
		$\checkmark$	Administrator	
			User	
	Ok		Cancel	

You must enter a name for the new group. Roles can be assigned as needed. Members can be assigned to the group through drag and drop from the User Management UI:

User Management	$\otimes$	
Users User Groups		
Q R	Edit UserGroup	$\otimes$
Active Name	Name Group 1	
👗 🧭 User1 💶	Members	Roles
👗 🕜 names 📻		Administrator
		User
	Ok	Cancel

Click OK to save the group.

#### 5.4.2.2 Editing a user group

The name, members and roles of a user group can be edited by right-clicking the user group in the list and selecting "Edit" from the context menu.

#### 5.4.2.3 **Deleting a user group**

To delete a user group, right-click the group in the list and select "Delete". You will be prompted to confirm deletion. Once confirmed, any users inheriting roles from the group will lose those roles.



## 5.5 Role management

In NAMES, a role is defined as a collection of individual permissions that can be assigned to a user or user group. The default role "Administrator" has all permissions and cannot be deleted. Additional roles with reduced permissions may freely be defined.

To open the Role Management GUI, select "Role Management" from the "Maintenance" menu:

Role Management	$\otimes$
🛖 Create 🛛 Remove 🌘	Save
Role Administrator	•
> 🗹 CA	^
Configurations	
> 🗹 Firmware	
JobLogShow	
) 🗸 Jobs	
> 🗹 Music on Hold	
> 📝 Roles	
> 🗹 SSL Contexts	
Settings	
ShutDown	*
Close	

## 5.5.1 Creating a role

To create a role, click the "Create" button. The role creation dialogue is displayed:

Create Ro	le		$\otimes$
Name	User		
	Ok	Cancel	

Enter a name for the role and click "OK". The role is created.



## 5.5.2 Assigning permissions to a role

To assign permissions to a role, select the role you wish to modify from the "Role" combo box. The currently assigned permissions are displayed in a tree structure, with different permissions (create, read, update, delete) for the same object type collected under a common heading:

Role	test	-
× 🔳	Jobs	*
$\sim$	/ JobCreate	
	JobDelete	0
	JobEdit	
	JobShow	

The checkboxes are tri-state, and the meaning differs slightly between permissions and group headings:

The permission is not granted / no permissions are granted.



The permission is granted / all permissions are granted.

The permission is implicitly granted / some permissions are granted.

Implicit permissions result when a permission that is explicitly granted requires another permission to work properly. In the above example, to be able to create a job, you must also be able to view the job list.

After adjusting the permissions as required, click the "Save" button to persist your changes.

## 5.5.3 Deleting a role

To delete a role, select the role you wish to remove from the combo box and click the "Remove" button. You will be prompted to confirm the deletion.

## 5.6 SNMP configuration

NAMES can send SNMP traps/notifications to a network monitoring tool to alert you about various events and conditions, ranging from NAMES start up and shutdown through loss of database connectivity to various target events (CallHome Events) which are mapped to SNMP.

In order to send SNMP traps to your monitoring tool, the correct settings must be configured in the "SNMP Configuration" dialogue available from the "Maintenance" menu:



SNMP Settings		6
🐼 Save Set	tings 🛯 🧟 Send Test Trap	
Version	Version 1	•
IP Address	127.0.0.1	
Port	162	
Community	public	
Send Inform		
Security Level	No Auth / No Privacy	
User Name	user	
Password		
Auth Protocol	SHA-1	
Privacy Protocol	AES-256	~
Receiver Engine ID		
	Close	

The settings should be configured to match the network monitoring system in use. Some settings are enabled and disabled depending on other settings, primarily the SNMP version, as not all settings are required or supported for all versions.

# 5.7 Certificate Authority configuration

To use the "Sign Certificates" job to provide a TLS-enabled target with the certificates required for secured operation, the integrated NAMES certificate authority must first be configured properly. Properly configuring both the targets and NAMES for TLS-secured operation requires a working knowledge of asymmetric encryption, PKIs and TLS. Providing this is outside the scope of this document; it is recommended that administrators acquire this knowledge from other sources.

To configure the built-in certificate authority (key, certificate, signing policy) open the "Certificate Authority" dialogue from the "Maintenance" menu:



📢 Start Wizard	🔑 Setup Private Key 🤵 Setup Certificate 📄 Upload Certificate 💥 Setup Policy
	Private Key
	Key Length N/A
	Fingerprint N/A
	Certificate
	Serial N/A
	Fingerprint N/A
	Subject N/A
	Issuer N/A
	Valid from 19.08.2014 10:40:45 MESZ
	Valid until 19.08.2014 10:40:45 MESZ
	Download CA Certificate

This dialogue shows information about the currently configured RSA key and matching certificate. To begin configuring the certificate authority, either click the "Start Wizard" button to be guided through the configuration, or use the other buttons to directly open the section you wish to configure. In the following description screenshots from the wizard mode will be used, the resulting dialogues are however identical to the individually selected dialogues except for the buttons at the bottom.

There are a number of different ways to configure your certificate authority, both with regards to how key and certificate material is acquired and whether NAMES is integrated into an existing PKI or is configured as a root certificate authority.

## 5.7.1 General configuration procedure

In all scenarios, the certificate authority key and certificate as well as signing policy must be configured. The first step is always to configure the key:



ficate Auth	ority Management	(
	👽 Start Wizard 🛛 🔑 Setup Private Key 🛛 🧁 Setup Certificate 📄 Upload Certificate 💥 Setup Policy	
	Setup Private Key	
	Upload Upload private key	
	Generate Generate Key RSA Key Length 2048	
	Cancel Previous Next	
	Close	

The key can either be uploaded in the form of an unencrypted PEM-encoded RSA key, or generated by NAMES. When generating a key, you can select a key length or 1024, 2048 or 4096 bits. Depending on the selected length of the key and random chance, generation of an appropriate key may take some time.

After configuring the key, a matching certificate has to be configured. For details of how to configure the certificate, see sections 5.7.2 to 5.7.4.

Finally you have to configure the signing policy. The signing policy determines both: Which distinguished names the certificate authority will accept in a certificate signing request and for how many days the issued certificates will be valid.



etup Policy							
Policy				_			
Email	Match	Supplied	<ul> <li>Ignore</li> </ul>				
Common name	Match	Supplied	O Ignore				
Country name	O Match	Supplied	Ignore				
State/Province	Match	Supplied	Ignore				
Locality name	Match	Supplied	Ignore				
Organization name	Match	Supplied	Ignore				
Organizational unit	O Match	Supplied	Ignore				
Policy							
Client validity (days	Client validity (days)						
Apply Settings							
	·····						
	Close						

For each distinguished name component, it can be specified whether the value in the request has to **match** the corresponding value in the certificate authority's certificate, simply be **supplied** but can have any value or is completely **ignored** and thus may also be unset.

## 5.7.2 Configuring NAMES as a Root CA

The simplest way to configure NAMES is as a Root CA. Begin by generating a RSA key and then generate a selfsigned certificate. To do this, you will need to enter the distinguished name of the certificate authority you are setting up in the "Setup Certificate" dialogue. Select how long the self-signed certificate should be valid and finally click the "Generate Self-Signed" button:



tup Certificate	
Distinguished Name	
Email	
Common name	NAMES-CA
Country name	DE
State/Province	NRW
Locality name	PB
Organization name	NovaTec
Organizational unit	Labor
Certificate Signing Request Download CSR	
Self-Signed Certificate Generate Self-Signed	Certificate Validity 730

The generated certificate will be sent to your browser for use in other applications' trust stores. It can be redownloaded later from the CA information dialogue. For security reasons, generated RSA keys cannot be downloaded from NAMES.

After configuring your policies as described above, your CA is ready to use. Please note that the NAMES CA can only be used to issue certificates to NovaTec devices, not to other devices or software tools. You will therefore need another CA to issue certificates to these and will have to configure trust relationships accordingly.

## 5.7.3 Configuring NAMES as a subordinate CA

When using NAMES with an existing PKI, it may be more convenient to configure it as a subordinate certificate authority under the existing hierarchy. To accomplish this, proceed as in section 5.7.2 above, but do not generate a self-signed certificate. Instead, click the "Download CSR" button in the "Setup Certificate" dialogue to generate a Certificate Signing Request.

This CSR then has to be submitted to the root or intermediate CA, under which the NAMES CA is to be inserted. A corresponding certificate has to be issued, taking care to include correct usage restrictions; appropriate information is contained in the CSR, but CA policy may discard the extension requests. Once the certificate has been issued, it has to be uploaded to NAMES through the "Upload Certificate" dialogue, reached from the "Certificate Authority Management" dialogue:



Upload Certificate		$\otimes$
Upload	Upload CA certificate Close	

The certificate file has to contain the certificate with full verification chain in PEM-encoded format. After configuring signing policy, the certificate authority is ready for use.

## 5.7.4 Configuring NAMES using an existing key and certificate

If an existing key and certificate are to be reused for NAMES, or key and certificate are to be generated externally, both can be uploaded to NAMES. First upload the key as explained in section 5.7.1, then upload the certificate as explained in section 5.7.3. You may need to convert existing files into the required formats (PEM-encoded, no encryption). Configure the policy and the certificate authority is ready for use.

# **5.8 SSL contexts**

In order for NAMES to communicate with targets configured for secure maintenance (TLS encrypted/authenticated MNT and/or CH connections), SSL Contexts must be configured. These contexts contain the RSA key used by NAMES, a corresponding certificate and a collection of certificates for all trusted Certificate Authorities. NAMES does not automatically trust its own CA, so you will need to add the certificate for the internal CA even if using NAMES to certify the targets.

You can have multiple SSL Contexts in use at the same time, for example when migrating from one PKI to another, or when using different PKIs for different network segments or clients. The SSL Contexts will later be assigned to specific targets or CallHome servers; a default SSL Context can also be selected.

To begin configuring SSL Contexts, select "SSL Contexts" from the "Gateway Management" menu:


# 5.8.1 Creating an SSL context

To create a new SSL Context, click the "Create" button. Specify a descriptive name for the new context and click OK:

Create SSL Context		$\otimes$
Enter name for new SSL Context	Current PKI	
Ok	Cancel	_

The new context will now appear in the "SSL Context" combo box and can be edited as described in section 5.8.2.

# 5.8.2 Editing an SSL context

Each SSL Context must contain exactly one entry in the "Certificates" table and at least one entry in the "Trusted Certificate Authorities" table. Multiple own certificates are supported in principle, however, as current firmware versions do not supply a list of trusted CAs during TLS handshake, NAMES cannot select an appropriate certificate. To ensure the correct one is used, only one should be configured at a time.

Warning: editing an existing context which is in use by one or more targets/CallHome servers may cause connections to these targets/servers to fail while changes are being made.

# 5.8.2.1 Adding a private key and certificate

First, right-click in the "Certificates" table and select "Create" from the context menu. The "Upload Private Key and Certificate" dialogue is displayed:



Upload Private Key a	nd Certif	îcate	$\otimes$
Alias		key	
Password		•••••	
Select Private	Кеу	mntkey.pem	
Select Certifi	cate	mnt.crt	
Ok		Cancel	

Fill in a descriptive alias for the key pair and then select a private key file and a certificate file for upload. These files must contain an RSA private key and a corresponding certificate, both in PEM format. The certificate file should contain the entire certificate chain without the Root CA certificate if the signing Certificate Authority is not the Root CA. If the key is encrypted, you must also supply the correct password for decryption. Finally, click "OK" to upload the files.

If the import process was successful an entry containing basic information about key and certificate will be displayed in the "Certificates" table:

Alias	Кеу Туре	Distinguished Name
key	RSA-1024	CN=MNT, OU=Entwicklung, O=NovaTec
~ 7	1021	CH-HIT, CO-Entwickling, O-Hovarce

#### 5.8.2.2 **Replacing a private key and certificate**

To replace a private key and certificate for an SSL Context, you must first remove the current key and certificate. To do this right-click the entry in the "Certificates" table and select "Remove" from the context menu. After removing the current entry proceed as described above.

#### 5.8.2.3 Adding a trusted certificate authority

You must add at least one entry to the "Trusted Certificate Authorities" table. Multiple CAs may be added if necessary, for example if targets are signed by different CAs, but trust the same CA. To add a trusted certificate authority, right-click in the "Trusted Certificate Authorities" table and select "Create" from the context menu:

Upload CA Certificate	$\otimes$
Alias	са
Select File	CACERT.CRT
Ok	Cancel

Fill in a descriptive alias (this must differ from any other alias used in the same context, including the alias for the "Certificates" table entry) and select a PEM-encoded certificate for upload, then click OK.

If the import process was successful, an entry containing basic information about the certificate is displayed in the "Trusted Certificate Authorities" table:



Alias	Distinguished Name
са	C=DE, ST=NRW, L=Paderborn, O=NovaTec, OU=Entw

# 5.8.2.4 **Removing a trusted certificate authority**

To remove a trusted CA from the list, right-click it's entry in the table and select "Remove" from the context menu.

# 5.8.3 Setting an SSL context as default context

You may assign a "Default Context", which means this SSL Context will be assigned as the context for newly created targets or CallHome servers by default. To choose the default context, simply select the context from the combo box and check the "Default" check box.

# 5.8.4 Removing an SSL context

To remove an SSL Context, select the context you wish to remove from the combo box, than click the "Remove" button at the top. If the "Remove" button is greyed out, the context is in use and cannot currently be removed. You must first remove the context from any targets and CallHome servers that may be using it.

# 5.9 Managing firmware images, music on hold files and Licence Manager

For certain operations binary files need to be uploaded to NAMES first. Specifically these are firmware images, Music on Hold files and licence files.

# 5.9.1 Firmware images

Firmware images are managed through the "Firmware Images" window, which can be opened from the "Gateway Management" menu:



s		$\otimes$
ersion	Descri	ption
	1000	
	s	s ersion Descri

To add a firmware image to NAMES for use in "Upload Firmware" jobs, right-click in the table and select "Upload" from the context menu. The "Upload Firmware" dialogue opens. Specify a description for the firmware (for example, the version of the firmware you are uploading) and select the firmware image you wish to upload:

Upload Firmware	$\otimes$
Description 00090000	
Browse FW 00090000 TI CLIENT.RT(	
Ok	

After clicking "OK", the firmware image will be sent to the NAMES server and stored in the database. It is displayed in the table:

Firmware Images	$\otimes$
Version -	Description
FW_00090000_TI_CLIENT.F	0009000
	Close

To remove a firmware image from NAMES, right-click the entry in the table and select "Delete", then confirm the deletion in the following dialogue.

# 5.9.2 Music on Hold

Music on Hold files are managed through the "Music on Hold Management" window, accessible from the "Gateway Management" menu:



Music on Hold Mar	nagement	$\otimes$
Name	Description	
	Close	

To upload a Music on Hold file, right-click and select "Upload".

Upload Music on Hold	$\otimes$
Description hello MoH Name hello	
Browse hello.wav	
Ok Cancel	

After entering a description, which can be any text, and selecting the desired music file, click "OK" to upload the file to NAMES. If the music file is in the correct format (see NovaTec Configuration utility for further details), the file is imported and a new entry appears in the table:

Description A	
hello	
	Description ← hello

The Music on Hold is now ready for use.



To remove a Music on Hold file from the database, right-click the entry in the table and select "Delete", then confirm deletion in the following dialogue.

# 5.9.3 Licence Manager

Licenses are managed through the "Licence Manager" window, which can be opened from the "Gateway Management" menu:



To add a licence to NAMES for use in "Upload Licence" jobs, right-click in the table and select "Upload" from the context menu. The "Upload Licence" dialogue opens. Specify a description for the licence and select the licence you wish to upload:

Upload Licence		$\otimes$
Description	Sammel-Licence	
Browse S7	7-S21 firmware.lic	
Ok	Cancel	

After clicking "OK", the licence will be sent to the NAMES server and stored in the database. It is displayed in the table:

Licence Manager	$\otimes$
Description	Version
Sammel-Licence	00.09.00.XX
	Close

To remove a licence from NAMES, right-click the entry in the table and select "Delete", then confirm the deletion in the following dialogue.

Copyright 2017 NovaTec Kommunikationstechnik GmbH



NAMES will automatically select a licence for use with a device and include it in the configuration. The licence is selected from those available by the device MAC address, the version of the currently installed firmware, whether the number of licenced channels supports the configured amount, and finally by the amount of features licenced.

# 5.10 Shutting NAMES down

To shut NAMES down, you have several options. From the web UI, you can shut NAMES down "gracefully", which means that no more jobs will be started and the program will exit after all running jobs have been completed, or immediately, which means that any running jobs will be aborted.

To shut down NAMES, select "Server Shutdown" from the "Maintenance" menu. The shutdown dialogue will appear:



The "Graceful shutdown" option is checked by default. To perform an immediate shutdown, aborting all running jobs, deselect the option. After clicking "Yes", NAMES will shut down either immediately or after all running jobs have finished. As this action also shuts down the embedded web server, no further feedback is provided. The web UI will report that it has lost its connection to the server.

You can also shut down NAMES from the Windows Server Manager UI. This should however only be done as a last resort, if a shutdown through the web UI is not possible.



# 6 Usage

# 6.1 Provisioning

This chapter describes how to provision NovaTec systems with the NAMES 3.0 software. Only CCU4 and later systems are supported.

All NovaTec systems are configured to use DHCP by default. After hardware assembly and initial system boot, the system will query DHCP. The response must contain option 129 with the IP address of the NAMES server. The default host name of the system is "novatec<MAC Address>" (e.g. "novatec8058C5000123").

If the DHCP query is successful, the device will attempt to connect to NAMES. Depending on the NAMES security settings, a new entry may be created if the device is unknown, using the System ID (either the CCU serial number or the backplane ID) as its name.

Targets Target Groups			
Q R			
Name -	Address	Backplane	
Ø 000000C12B0	192.168.200.250:800	0000000C12B0	
Targets Target Groups			
Q R			
Name 🔺	Address	Backplane	
IF5050-137-1241-R2B	192.168.100.1:800	000014870D37	

If the network configuration and NAMES IP address cannot be retrieved via DHCP, it must be manually configured through the USB console connection.

The system acts as a USB serial device; when plugged into a Windows PC, it will automatically be assigned as a COM port. Using this COM port, a serial console connection to the device may be established with a serial terminal utility such as PuTTY.



#### Version 1.1 (final Version)





When prompted for the user name, enter "technik". The default password is empty; when prompted for a password, press return.

Version 1.1 (final Version)



login as: technik	Putty	
	login as: technik	^
		=



#### The command

"netconf -i 192.168.1.10 -n	255.255.0.0 -g $192.168.0.1 -s$
sets the system if address, the neuro	ask and the default galeway address and saves them.
Details:	
"netconf –i xxx.xxx.xxx.xxx"	temporarily sets the system IP address.
"netconf –n xxx.xxx.xxx.xxx"	temporarily sets the netmask.
"netconf –g xxx.xxx.xxx.xxx"	temporarily sets the default gateway address.
"netconf –s	saves the temporary values as new values. The LAN link will automatically be cycled to activate the new settings. If the system is currently in the default configuration, the settings will remain active after a system restart.
"netconf"	displays the current and new settings.

As of May 5th, 2016

Version 1.1 (final Version)



```
"shownamescfg"
"setnamesaddr <IP> [port] [ToS] [TLS]"
"setnamesaddr -d"
```

displays the currently configured NAMES servers. sets the NAMES server to connect to. deletes the NAMES server configured through the console.

Both the IP configuration and the NAMES server address are not written to the configuration file, but to a separate storage that persists through a factory reset. The configuration through the serial console should therefore only be necessary once, as long as the configured information does not change.

# 6.2 Configuring the system

To start configuring a system, select it from the list once it has connected to the NAMES server, then press the button marked "Configure". The hardware components present in the system (chassis S8 and S21, modules and boards) are autodetected during startup if the system is in default and shown as part of the configuration. Older chassis that cannot be autodetected will be displayed as an S20 chassis. The chassis type may be changed without losing the already configured modules and boards, as long as the configured slot exists in the new chassis (see chapter 6.2.2.1.1).

#### Important: the CCU should always be inserted into slot 1 of the chassis!

Targets Target Groups			
Q R			Get Gateway Log
			Get Trace Files
Name 🔺	Address	Backplane	Manage Call Data Red
IF5050-137-1241-R2B	192.168.100.1:800	000014870D37	Reset Gateway
			Update Firmware
			Configure
			Create Job Trigge
			Edit Job Triggers
			Schedule New Jo

After clicking the "Configure" button, the following window will open if the system is connected to NAMES ("online"):



Configuration:	Running	▼ Manage
<ul> <li>System Setting</li> <li>System Info</li> <li>Network</li> <li>NAME Serve</li> <li>Remote According</li> <li>Time Setting</li> </ul>	js rmation rs ess js	8
Monitoring		
Hardware		
Security		
Telephony		
Source	:	

Before any changes can be made to the configuration, it must be switched to edit mode by pressing the edit button. This will start an exclusive edit session. The user will be unable to switch to edit mode if another user is already editing the configuration.

Configuration Win	dow for 1F5050-246-1423-R2I	C	Edit
Configuration:	Running	•	Manage

After switching to edit mode, the edit button is replaced by the "Commit" and "Cancel" buttons.

Configuration Win	dow for 1F5050-246-1423-R	2D		Commit	Cancol	
Configuration:	Running	V	Manage			

The "Commit" button commits all changes made during the edit session to the edited configuration. Pressing the "Cancel" button on the other hand ends the edit session without storing any of the changes and reverts to the state before starting the edit session.

The configuration options available with the configuration plugin installed with NAMES 3.0 (configuration / plugin version 1.0) are described in the following sections. These options may differ when using a different configuration version and plugin; appropriate information will be contained in the documentation of the specific configuration plugin. The following sections are structured in correspondence with the configuration tree in the left panel of the configuration window.



# 6.2.1 System Settings

#### 6.2.1.1 System Information

The "System Information" screen allows the user to configure several settings that are purely informational and do not influence the operation of the system. The following settings are available:

- Administrator: the email address of the administrator responsible for the system.
- System Name: a descriptive name for the system. This is not the same as the hostname.
- Description: any extra information about the system.
- Location: the physical location of the system.

System Informatio	n 🛛
Administrator:	default@novatec.de
System Name:	Default
Description:	System is running in default mode.
Location:	

#### 6.2.1.2 **Network**

The "Network" panel allows configuration of basic networking settings.

#### 6.2.1.2.1 Mode

This basic setting determines whether the IP configuration is static (manually configured) or dynamic (configured by DHCP). When in dynamic mode, only the settings "Hostname", "Single Port" and "VLAN" are available, as the other settings are configured automatically at system boot.

NovaTec

Version 1.1 (final Version)

Address		
Mode:	Dynamic *	
lostname		
🗸 Single	Port Outpu	
Interface S	Jystem	
MTU	1500	
IP Settin	gs	
Interface F		
IP Settin	ns	
II Detem	3-	
		_
Default Ga	teway	
IPv4:		
IPv6:		
DNS Serve	na)	
DNS Sen	ver	
VLAN		
	VLAN	
Use V	VLAN	

In static mode, all settings must be made manually. In particular, at least one IP address must be added to the "System" interface (SIP and management traffic), as well as to the "RTP" interface if RTP is to be used.



Version 1.1 (final Version)

	Network 🛙
	Address
	Mode: Static *
	Hostname Single Port Outpu
	Interface System
	MTU 1500 ,
	(Interface RTP)
	IP Settings
	IP Settings - System 🛞
	Mode: IPv4  Mode: IPv6
Interface System	Address: Address: Address: Address:
Add Edit Remove	Type of Service:     0     *       Ok     Cancel     Ok

To add an IP address to an interface, right-click the table "IP Settings" and select "Add" from the context menu. You may choose either IPv4 or IPv6 from the "Mode" dropdown in the following dialogue, then specify the appropriate settings for the type of address.

#### 6.2.1.2.2 Hostname

The hostname should be unique in the DNS domain the system is a part of. It is provided with DHCP requests and, if the DHCP in use is configured to provide dynamic DNS, can then be resolved to the assigned IP address. For this reason, the hostname must be provided if the mode is "dynamic".

#### 6.2.1.2.3 Single Port

By default, traffic from the system interface (management and SIP traffic) is routed through a different physical port than traffic from the RTP interface. If this option is checked, all traffic will be routed through a single port (the "SIP" port in the image below).



DB.NAMESMAN30.NT

As of May 5th, 2016

Copyright 2017 NovaTec Kommunikationstechnik GmbH



#### 6.2.1.2.4 MTU (Maximum Transfer Unit)

This setting specifies the maximum size of a single Ethernet frame. Typically, this is set to 1500, but some installations may require smaller numbers.

#### 6.2.1.2.5 Default Gateway

This setting specifies the IP address (IPv4 or IPv6) of the default gateway. This is the address of the gateway/router as seen from inside the LAN.

Pv4:		
Pv6:		
DNS Servers		
DNS Server		
	Add	
	Edit	
	Remove	

#### 6.2.1.2.6 DNS Servers

The DNS servers table lists the DNS servers that the system should use for resolving hostnames into IP addresses. At least one DNS server must be entered here.

To add or delete a DNS server entry, right-click the table to bring up the context menu.

DNS Server		$\otimes$
IP address:		
	Ok Cancel	

#### 6.2.1.2.7 VLAN

To emit Ethernet frames with an IEEE 802.1Q VLAN tag, tick the "Use VLAN" checkbox and enter the values to be included in the tag:

• ID:

the VLAN ID (VID) with which frames should be emitted.

• Priority (PCP): the Priority Code Point (PCP) for the frames emitted by the system.

	,	( )	,	'
VLAN				]
Use \	/LAN			
п	0	A Priority 0		
	0	- I Honey U	~	



#### 6.2.1.3 NAMES Servers

This table allows you to specify one or more NAMES servers for the system to connect to, in addition to any servers retrieved from DHCP or configured via the serial console. If multiple NAMES servers are configured, the system will attempt to connect to them in the listed order; if the first server cannot be reached, a connection to the second server is attempted, and so forth. The system will only connect to one NAMES server at a time. The option to have multiple servers is available mainly for failover in case of failure of a NAMES server.

NAME Servers 🕮			NAMES Server		$\otimes$	NAMES Serve	r	⊗
NAMES Server Instances	)		IP address:			IP address:		
IP Address	Port	Use TLS	Type of service:	0		Traffic class	0	
	Add		Туре:	IPv4	-	Туре:	IPv6	*
	Edit		Port:	0	- <b>A</b> - V	Port:	0	.▲ 
	Rem	ove	Use TLS			Use TLS		
				Ok Cancel			Ok	J

To add, edit or remove NAMES servers, right-click the table to bring up the context menu. When adding or editing a NAMES server, the following settings are available:

- IP address: the IP address of the NAMES server.
- Type of service/Traffic Class: a six-bit Differentiated Services Code Point (DSCP) for connections to this NAMES server.
- Type: whether the connection should be made via IPv4 or IPv6.
  - Port: the port the NAMES server is configured to listen on.



#### 6.2.1.4 Time Settings

This section allows the configuration of how the system time should be set. There are multiple possible sources for the system to acquire the current time (NTP, NAMES or ISDN). One or more of these sources can be configured and arranged in the order of priority by dragging and dropping.

To add a time source, right-click the table and bring up the context menu. When adding an NTP time source, the IP address/hostname of the NTP server and the query frequency must be configured. When using NAMES as a time source, time is synchronized to the NAMES server time on every NAMES heartbeat (once per minute). When using ISDN as a time source, time is synchronized with the ISDN network on every outgoing call.

#### 6.2.1.4.1 Time zone

In order to calculate the correct local time from the UTC system time, a time zone must be provided. The available time zones are in the format "<Continent>/<City>", e.g. "Europe/Berlin", and the list of suggestions can be filtered by typing in several letters of the desired zone's name.

#### 6.2.1.4.2 Daylight Savings Time

For time zones which make use of Daylight Savings Time (DST), the appropriate adjustment of system local time offset may be enabled or disabled. If enabled, three modes are supported:

- Static: DST starts and ends at the manually configured date and time.
- NAMES: the DST start and end times are managed by NAMES and adjusted according to the information provided by the Java Runtime Environment.
- Automatic: available only for (most) European time zones, this setting allows the system to manage DST itself according to the schedule used by European countries.

Time Settings 💠	Time source 🛞
Time Sources       Domain     Parameter	Domain: NTP
Timezone ID: Daylight Saving Time settings	Domain: NAMES +
✓ Enable Daylight Saving Time         Mode:       Static         ✓       Start:       02/18/2016       ↓         02/18/2016       ↓       08:54       ↓	Time source   Domain: ISDN  Cancel

Version 1.1 (final Version)



ID:	Eur	
-	Europe/Tiraspol	<b>^</b>
Daylig	Europe/Ljubljana	
V F	Europe/Berlin	
· ·	Europe/Moscow	0
Mode	Europe/Chisinau	
Start	Europe/Stockholm	* 13·31 *
E	Europe/Budapest	• 10.01 •
-	Europe/Zagreb	
	Europe/Helsinki	
	Europe/Paris	

## 6.2.1.5 Monitoring

The Monitoring section allows the configuration of conditions and thresholds that will cause an alarm message to be sent to the NAMES server. Alarm messages may trigger jobs if configured that way (see section **Fehler! Verweisquelle konnte nicht gefunden werden.**), and are propagated as SNMP notifications if SNMP is properly configured in NAMES.

There are "parameterless alarms" which have either no parameters or no individual parameters (for ASR alarms), and there are alarms which need further configuration (thresholds).

To activate or deactivate a parameterless alarm, simply drag and drop the corresponding entry from the "inactive" table to the "active" table or vice versa. Multiple alarms may be moved at one time by holding Shift or Ctrl while selecting from the table.

#### 6.2.1.5.1 Parameterless alarms

The following parameterless alarms are currently supported:

- **Call data storage full** The system's storage area for CDRs is nearly full and should be emptied.
- System ASR below threshold
- The ASR (attempt successful rate) for the entire system has fallen below the defined threshold.
- **ISDN ASR below threshold** The ASR (attempt successful rate) for ISDN call legs has fallen below the defined threshold.
- **SIP ASR below threshold** The ASR (attempt successful rate) for SIP call legs has fallen below the defined threshold.
- Layer 1 active An ISDN interface's layer 1 has switched from inactive to active.
- Layer 1 inactive An ISDN interface's layer 1 has switched from active to inactive.
- Layer 2 active An ISDN interface's layer 2 has switched from inactive to active.
- Layer 2 inactive An ISDN interface's layer 2 has switched from active to inactive.
- TLS certificate invalid in one week
  - The system's TLS certificate will become invalid in one week's time.
- **TLS has default time** The system time has not been properly set when attempting to verify TLS certificates.
- TLS own chain invalid The system's TLS certificate chain could not be validated.
   Log storage full
  - The system's log storage area is full and should be emptied.
- **Trace storage full** The system's storage area for trace files is full and should be emptied.



• System started

The system has successfully booted.

- Trace fatal
  - A fatal error has occurred. This alarm is sent after the system has rebooted following the fatal error.
- Trace warning
  - The system has registered a warning.
- **Trace error** The system has registered an error.
- **Invalid FW license** The system does not have a valid firmware license.
- TLS unlicensed The system does not have a valid TLS license/the TLS flag in the license is not set.
   PSU redundancy failure
- The system has lost PSU redundancy due to hardware failure or power loss. This alarm is only available with S8 and S21 chassis.
- **PSU redundancy restored** The system has regained PSU redundancy after a hardware failure or power loss. This notification is only available with S8 and S21 chassis.
- **RMCS connection lost** The system has lost its connection to the RMCS server.
- **RMCS connection attempt failed** The system's attempt to connect to an RMCS server failed.

#### 6.2.1.5.2 CPU usage Alarm

The CPU usage alarm is triggered by CPU load above the configured *alarm threshold* for a minimum time specified by the *alarm condition delay* – shorter spikes are ignored. Inversely, the alarm is cleared once the CPU load has dropped below the configured clear threshold for a minimum time specified by clear condition delay. Both the alarm and the clear are sent only if the corresponding checkbox is checked.

## 6.2.1.5.3 Call Setup Time Alarm

If the Call Setup Time (time to set up a call from the initial attempt to ringing or an error state) of a call exceeds the threshold specified, an alarm will be sent. The clear is sent once the Call Setup Time drops below the configured clear threshold again. Both the alarm and the clear are sent only if the corresponding checkbox is checked.

#### 6.2.1.5.4 Memory Full Alarm

The memory full alarm is triggered by free memory below the configured *alarm threshold* for a minimum time specified by the *alarm condition delay* – shorter spikes are ignored. Inversely, the alarm is cleared once the free memory has increased above the configured clear threshold for a minimum time specified by clear condition delay. Both the alarm and the clear are sent only if the corresponding checkbox is checked.

#### 6.2.1.5.5 Heartbeat

The system regularly generates a heartbeat signal that is sent to the NAMES server for liveness monitoring. The heartbeat interval in seconds can be configured.

Version 1.1 (final Version)



Active			Inactive		
			System ASR below thresh	old	
			Layer 1 active		
			Layer 2 inactive		
			Log storage tull		
CPU Usage Alarm					
Send Alarm			Send Clear		
Alarm threshold (%):		1	Alarm condition delay (s):		
Clear threshold (%): Clear condition delay (s):					
Call Setup Time					
Send Alarm			Send Clear		
Alarm threshold (ms):		(	Clear threshold (ms):		
Memory Full Alarm					
Send Alarm			Send Clear		
Clear threshold (KB):		(	Clear condition delay (s):		
Alarm threshold (KB):		4	Alarm condition delay (s):		
Heartbeat					
Repeat Interval (s):	60				
ASR Settings					

#### 6.2.1.5.6 ASR Settings

The ASR (Attempt Successful Rate) is the percentage of successful connection attempts compared to the total number of connection attempts. The ASR settings are used to determine the threshold for ASR alarms. The alarms themselves can be separately enabled or disabled for ISDN and SIP calls and overall calls, see section 6.2.1.5.1 oben.

• Minimal call duration

Calls that do not last at least the length specified here are always rated as being successful.

• Alarm Trigger ASR

If the ASR falls short of this limit, a call home is initiated. Values from 0 to 100 % are possible.

• Minimal calls for Alarm

This is a counter, which allows the system time to carry out the number of calls specified here, before the ASR is considered to be below the value set above. For example if this value is set to 1, then after a reset the first call that falls below the ASR will trigger the event ASR call home (if active).

Right-click into the free space in the window "ASR Settings" and select "Add". The appropriate windows for the ASR alarm settings appear.



ASR Settings				
Context M	inimal Call Duration (s)	Alarm Trigger ASR (%	) Minimal Calls for A	Varm
	Add Edit Remove			
ASR Setting 🛞	ASR Setting	$\otimes$	ASR Setting	$\otimes$
Context: System   Minimal Call Duration (s): Alarm Trigger ASR (%): Minimal Calls for Alarm:	Context: Minimal Call Duration (s): Alarm Trigger ASR (%): Minimal Calls for Alarm:	ISDN Network *	Context: Minimal Call Duration (s): Alarm Trigger ASR (%): Minimal Calls for Alarm:	SIP Network *
Ok Cancel	Ok	Cancel	Ok	Cancel

The configured ASR alarms can be edited or removed. In you wish to change an ASR alarm, click on the corresponding alarm with the right mouse key and then press "Edit". After you have made your changes click the "Commit" button.

If you want to remove an ASR alarm, click onto the corresponding alarm with the right mouse key and then onto "Remove". After you have made your changes, press the "Commit" button.

# 6.2.2 Hardware

#### 6.2.2.1 **Chassis**

In this section the hardware settings for a particular chassis and its components, interfaces, modules and their profiles can be made.

The following configuration is an example for the below explanations:

Click the menu "Chassis". The following window pops up after restarting the target:

Chassis 🖾
4 S21
Slot 1   CCU4
Slot 2   Empty
Slot 3   Empty
Slot 4   Empty
Slot 5   Empty
Slot 6   Empty
Slot 7   Empty
Slot 8   Empty
Slot 9   Empty
Slot 10   Empty
Slot 11   Empty
Slot 12   Empty
PSU 1  Present
PSU 2  Empty

In the above window an S21 configuration with one CCU4 in slot1 and one PSU1 is shown. It is also possible to choose other chassis like S5+, S6, S7, S8 and S20. These chassis appear in the list, if you click onto S21 in the window. In the slots below "Slot1" other modules (e.g. CAU or ULU) can be configured.

Copyright 2017 NovaTec Kommunikationstechnik GmbH



#### 6.2.2.1.1 Changing the chassis type

As mentioned in <u>chapter 6.2</u>, if an S5+, S6 or S7 is in use, this will be shown in the configuration of the unit after rebooting the target as an S20 chassis. To change the chassis type to the one currently in use, the following steps are necessary:

- Click onto "S20" in the window as shown below (Step 1), a dropdown menu will appear which contains all possible types of chassis to select from (Step 2).
- Select the type of chassis (S6). All slide cards and boards will remains as are available and detected during booting process (Step 3).



#### 6.2.2.1.2 Slide in cards and daughter boards

Click onto slot 1 of the chassis showing CCU4 as available. A table with the available daughter boards SO4, S2M2 and the amount of IP codecs is shown. You can also choose other daughter boards: ANA4, Uo4\_2B1Q or U04\_4B3T and Upo4.

Chassis 🛛
4 S21
<ul> <li>Slot 1   CCU4</li> </ul>
Number of VoIP codecs: 128
> Board 1   S04
> Board 2   S2M2

To view the interfaces and the settings of each daughter board, click onto the arrow on the left hand side of the corresponding board (here 1 or 2). Here a So4 on "Board 1" with four interfaces and on "Board 2" one S2M2 with two interfaces are available.

NovaTec

Version 1.1 (final Version)

S21
<ul> <li>Slot 1   CCU4</li> </ul>
Number of VoIP codecs: 128
Board 1   S04
ISDN Interface 1   Active  , Master
ISDN Interface 2   Active   , Master
ISDN Interface 3   Active   , Master
ISDN Interface 4   Active   , Master
# Board 2   S2M2
ISDN Interface 1   Active   , Master
ISDN Interface 2   Active   , Master

It is possible to modify the interface settings here. If you want to change the interface state from active to inactive mode, click onto the interface to be modified. A drop down window appears in which the desired mode can be selected.



If you wish to change the interface mode from master to slave mode or vice versa, right click the interface you wish to adapt. Click onto edit in the pop up menu. The "Interface Definition" window appears. Select the appropriate mode and add a comment like changing reasons, names or location etc. into the comment section.

Exceptions to this are UO4 and Uko4 daughter boards. These boards can only be in master mode. In case an ULU slide-in card exists in one of the slots, all interfaces of this card can be configured in master or slave mode as bunch. You cannot single out interfaces.

	Interface Definition 🛞	Interface Definition
	Mode: Master *	Mode: Slave +
<ul> <li>S21</li> <li>Slot 1   CCU4</li> <li>Number of VoIP codecs: 128</li> </ul>	Comment:	Comment:
Board 1   S04 ISDN Interface 1   A Edit	Ok Cancel	Ok Cancel

## 6.2.2.2 Analogue Profiles

In this section you will find a description of how to change the default configuration as provided by the system of every analogue interface if necessary.

Analogue Profiles 🛛								
ID	Max Hook Flash Duration	Call Charge PulseLength Type	Call Charge Pulse KHz	Caller ID	Country ID	Tone Detection		
Default	310	100	N_16_K_HZ	ETSI	Germany	Fax Tone		



If the given default configuration is useless for your application it can be changed like this: Click onto the appropriate "profile" with the right key of the mouse. A menu with "Add, Edit and Remove" is shown. Select "Edit" and change the parameter as required by your application.

If you wish to create a new profile, proceed as follows:

Right-click into the analogue profiles list. A menu with "Add, Edit and Remove" shows up. Select "Add" and choose the relevant settings for the particular location or country.

ID Max Hook Fla	sh Duration	Call Charge PulseLeng	th Type Call Charge Pulse KHz	Caller ID	Country ID	Tone Detectio
Default 310		10 Add Edit Remove	N_16_K_HZ	ETSI	Germany	Fax Tone
nalogue Profile		$\otimes$	Analogue Profile			$\otimes$
D:	Default		ID:			
lax Hook Flash Duration:	310		Max Hook Flash Dura	tion:	200 🛔	
all Charge PulseLength Type:	100		Call Charge PulseLe	ngth Type:	50	
all Charge Pulse KHz:	16kHz	-	Call Charge Pulse KH	Iz:	12kHz	-
aller ID:	ETSI	•	Caller ID:		Off	-
ountry ID:	Germany		Country ID:	[	Austria	Ŧ
one Detection:	Fax Tone	-	Tone Detection:		Off	*
Ok	Cancel			Ok C	Cancel	
	Edit			٨	ЧЧ	

# 6.2.2.3 VoIP Port Profiles

In this chapter you will find a description of how to define the necessary SIP VoIP port profiles. The port profile determines the basic functionality of the corresponding port. The default port profile is shown in the picture below. This profile is applied to all associated SIP interfaces. These are the general settings for all associated SIP interfaces regardless of the negotiated codec type between the SIP partners. These settings can be modified or a completely new profile can be created.

VoIP Port Profiles 🛛								
Name	Init JB Time	MinJBTime (	Max Playout Delay (ms)	Delay Decrease Ratio (%)	Delay Increase Max (ms)	Underrun (m	Overrun (ms	ISDN near
Default	180	20	180	40	40			on





VoIP Port	Profile					
Name:	Default					
Setting:	Adaptive		+			
				-		
Init JB	Time (ms):	80				
MinJB	Time (ms):	20		*		
Max Pl	ayout Delay (ms):	180				
Delay [	Decrease Ratio (%):	40		*		
Delay Increase Max (ms):		40		*		
	fort poise generatio		nabl	be		
Voice	guality enhancement	ni is e	labi	eu		
Voice	Voice quality enhancement					
Adaptive noise reduction						
Packet loss concealment to mask lost packets						
silen	Silence suppression					
Send comfort noise in SID packets						
	Ok	Cancel				

The VoIP port profile can be configured for two different modes:

Adaptive mode

Adaptive dejittering mode is designed to automatically adjust the Jitter Buffer Delay based on network conditions. The goal is to minimizes the time between packet reception and playout of its content on TDM, while keeping the jitter buffer large enough so that it can keep up with the current network jitter. To establish the size of the Jitter Buffer Delay, the Adaptive dejittering algorithm estimates the network delay as well as the network delay variations. It estimates these values based on packet reception. These estimations are made over time, so that sudden variations in packet flow do not trigger sudden variations in the delay, thus ensuring a smooth adaptation. Delay adjustments are made during silence periods: when decreasing the delay silence periods are shortened, while when increasing the delay, silence periods are stretched out. Note that while the delay may be modified, the PDV stays unchanged. This means that when the delay is reduced, it increases the amount of time by which a packet can be received in ahead of time. In turn, as the delay is increased, the amount of time allowed for packets received in advance is reduced.

Settings in JB mode: Adaptive

Init JB Time: 80 [ms]

Min. JB Time: 20 [ms]

Max. JB Time: 180 [ms]

Static mode

Static Adjustment dejittering is characterized by a constant Jitter Buffer Delay. Whenever overruns or underruns occur, the associated packets are dropped and the Jitter Buffer Delay is readjusted based on user configuration. Using this mode in a network where there is no or little jitter, the delay between the time a packet is received and the time its content is played on TDM is constant and around the initial delay configured.

Settings in JB mode: Static Init JB Time: 100 [ms]



Max. JB Time: 180 [ms]

• ISDN near end echo cancellation

Activates or deactivates the echo cancellation on the ISDN side of ISDN -> SIP connection leg

• Comfort Noise Generation is enabled

During periods of transmit silence, when no packets are sent, the NMG has a choice of what to present to the listener. Muting the channel (playing absolutely nothing) gives the listener the unpleasant impression that the line has gone dead. CNG generates a local noise signal that it presents to the listener during silent periods.

• Voice quality enhancement

The voice quality gets better.

- Adaptive noise reduction
- Packet loss concealment to mask lost packets

Packet loss concealment (PLC) is a technology designed to minimize the practical effect of lost packets in digital communications. In particular, PLC is used in Voice over Internet Protocol (VoIP).

• Silence suppression

Enables the codec to compress silence packets to minimize IP traffic. Please note, not all VoIP codecs support this option. For more information, please read the comments here.

Send comfort noise in SID packets

Comfort Noise (SCN) feature and the generation of Silence

Insertion Descriptor (SID) packets during silence periods. This parameter is applicable only when SilenceSuppressionFlag is enabled

• Underrun

In static jitter mode, average delay boundary, in milliseconds, at which the jitter buffer

detects an overrun condition and re-adjusts itself to reduce communication delay.

Overrun

In static jitter mode, average delay boundary, in milliseconds, at which the jitter buffer detects an overrun condition and re-adjusts itself to reduce communication delay.

There is no special handling of the Jitter Buffer Delay when overruns or underruns occur. In contrast with the Static Adjustment mode that makes a complete re-adjustment of its delay, Adaptive dejittering mode keeps on performing the same adjustments in order to find the

optimal delay for the current network conditions.

# 6.2.3 Security

This chapter explains the use of TLS and the associated settings as well as how to activate encryption for maintenance or SIP. Also signing via SCEP is described. You can define the size of keys in the window as shown below. The default setting is 2048 bits.



Version 1.1 (final Version)

TLS Settings		
Use TLS		
Key Size (bits):	1024 bits	
Configure Ma	aintenance and SI	P seperate

If you want to use TLS, the box "Use TLS" has to be ticked. After the "Use TLS" box is ticked, the key size can be changed and "Configure Maintenance and SIP seperately" as well as "Use SCEP" can be selected. Also the sub-items "TLS" and "SRTP/SIP" appear under "Security". In these sub-items you can configure the secured mode for SIP link and the link between the target and NAMES.

System Settings	Security 🛛
<ul> <li>Hardware</li> </ul>	TEEW
Chassis	TLS Setungs
Analogue Profiles	Use ILS
VoIP Port Profiles	Key Size (bits): 1024 bits •
<ul> <li>Security</li> </ul>	Configure Management and SIP seperately
TLS	
SRTP/SIP	Enable SCEP
Telephony	Use SCEP

In order to set up the "TLS" adjustments, click onto the submenu "TLS". The following drop down menu appears:

- Protocol version
  - Minimum TLS version

The selected value for the TLS link has to be provided from the connected partner.

Γ	Protocol Versions		
	Minimum TLS version:	TLSv1	•
L		TLSv1	
Γ	Cipher Options	TLSv1.1	
	Option	TLSv1.2	



#### Version 1.1 (final Version)

Cipher Options			
Option			
Verify Depth:	10 *		
Request Parameters			
Distinguished Name:		Challenge Password:	
Trusted Certificate Authonities			
Distinguished Name		Fingerprint	
SIP Authentication Flags	Client Authorities		
Server Authentication	Client Authentication		

The TLS submenu provides the following setting possibilities:

Cipher Options

is a standard collection of cryptographic processes for encryption.

Right-click the section "Cipher Options" and select "Add or Add All". A drop down menu with a choice of possible processes appears. If more than one process is provided you can change the priority ranking as follows:

Select the required cipher option and drag it up or down with your mouse.

Cipher options cannot be edited or changed, only removed. To remove an option, click onto it with the right mouse key and onto "Remove" in the pop up menu.

Cipher Opt	ions 🛞
Context:	ECDHE_RSA_WITH_AES T
	ECDHE_RSA_WITH_AES_256_GCM_SHA_384
	DHE_RSA_WITH_AES_256_GCM_SHA_384
	ECDHE_RSA_WITH_AES_256_CBC_SHA_384
	DHE_RSA_WITH_AES_256_CBC_SHA_256
	ECDHE_RSA_WITH_AES_256_CBC_SHA

• Verify Depth

With this option the depth of the verification of the certificate can be assigned. Request Parameters

• Distinguished Name:



Here the content of the "Distinguished Name" can be assigned to trigger a CSR request for later signing.

• Challenge Password:

If the optional "Challenge Password" in the registry of the "Certificate Authority Server" is activated, the two instances (MNT and SIP) of the NovaTec gateways will need an "One Time Password". The "Challenge Password" is a random string and can be transferred to NovaTec configuration by copy and paste.

Trusted Certificate Authorities

CA certificates can be loaded into the trust list of the NovaTec gateways.

Right-click into the "Trusted Certificate Authorities" window. Select "Add" from the pop up menu. A new window opens. Press "browse" and choose the required certificate, then press the "Ok" button.

	Trusted Certificate Authorities	
	Distinguished Name	Fingerprint
	CN=Zertifikatstell-CA	05:97:0a:48:48:d4:88:29:a1:5f:b0:74:5b:94:6b:3b:75:5c:81:
Certificate Upload (8)		
Browse Root-CA.cer		
Ok Cancel		

The content of certificates cannot be edited or changed, it can only be removed. To do so select the corresponding certificate right click it and select "Remove" from the pop up menu.

• SIP Authentication Flags

To increase the security of a link, the identity of the TLS partner has to be verified. This can be done with the following flags.

o SRTP/SIP

SRTP encryption options Enable 256-bit AES encryption (offer)	SRTP/SIP 🛛
Enable 256-bit AES encryption (offer)	SRTP encryption options
	Enable 256-bit AES encryption (offer)
Enable 80-bit HMACs (offer)	Enable 80-bit HMACs (offer)

#### • SRTP encryption options

If the sRTP mode (try to use or have to use) for SIP trunk has been activated (<u>see chapter</u> <u>6.2.4.2.1.4</u>), the following additional encryption methods will be provided after one of the selection boxes in the section "SRTP encryption options" has been ticked:

Enable 256-bit AES encryption (offer) Enable 80-bit HMACs (offer)	AES_CM_128_HMAC_SHA1_32
✓ Enable 256-bit AES encryption (offer)	AES_CM_128_HMAC_SHA1_32
Enable 80-bit HMACs (offer)	AES_CM_256_HMAC_SHA1_32
Enable 256-bit AES encryption (offer)	AES_CM_128_HMAC_SHA1_32
✓ Enable 80-bit HMACs (offer)	AES_CM_128_HMAC_SHA1_80
Mail Enable 256-bit AES encryption (offer)	AES_CM_128_HMAC_SHA1_32
✓ Enable 80-bit HMACs (offer)	

As of May 5th, 2016

Version 1.1 (final Version)



AES\_CM\_128\_HMAC\_SHA1\_80

AES\_CM\_256\_HMAC\_SHA1\_32 AES\_CM\_256\_HMAC\_SHA1\_80

If "Configure Management and SIP separately" has been ticked in addition to "Use TLS", a new sub menu appears under "Security". With these settings the TLS link between NAMES and the target as well as the secure SIP links of the targets can be configured separately.

System Settings	Security 🖾
<ul> <li>Hardware</li> </ul>	
Chassis	TLS Settings
Analogue Profiles	✓ Use TLS
VoIP Port Profiles	Key Size (bits): 2048 bits •
4 Security	Configure Management and SIP seperately
TLS (Management)	
TLS (VoIP)	Enable SCEP
SRTP/SIP	Use SCEP

The settings of the sub menu "TLS-Management" and "TLS-SIP" are identical to the settings of the sub menu "TLS".

If an SCEP server is used to sign the certificates, the box "Use SCEP" has to be ticked. The sub menu "SCEP" will appear under "Security" as soon as the box has been ticked.

System Settings	Security 🛛
<ul> <li>Hardware</li> <li>Security</li> <li>TLS (Management)</li> <li>TLS (Valp)</li> </ul>	TLS Settings ✓ Use TLS Key Size (bits): 2048 bits •
SRTP/SIP SCEP	Configure Management and SIP seperately
Zelephony Localisation	Enable SCEP

Once "UseSCEP" has been selected, following settings must be made:

Include the Microsoft Standard URL http://FQDN/certsrv/mscep/mscep.dll into the window "SCEP Server's URL". An extra DNS solution is required if you want to include the **F**ully **Q**ualified **D**omain **N**ame "FQDN" server domain (caserver1.novanet.local), which provides the trustworthiness of the remote partner.A server IP address can also be included instead of "FQDN". The SCEP Protocol is based on "http", therefore the default port number is always 80. Next step is to define the public key cryptography standard "PKCS#7" based algorithm for encryption and signature.

In accordance with the norms these are: DES, 3DES, Blowfish, md5 and sha1.

If a Microsoft Server is used as certificate authority for the enrollment with SCEP, two registration authority (RA) certificates for enrollment have to be imported from the Microsoft Server. The first is *"usage: Digital Signature, Non Repudiation*", a signed RA Certificate (Enrollment Certificate), and the second *"usage: Key Encipherment, Data Encipherment*" for encryption (Encipherment Certificate). Both must be exported from the



Version 1.1 (final Version)

certification authority of the CA server in base64 format. With the selection of the buttons "Import enrollment certificate" and "Import enciphernment certificate" these certificates can be transferred to the configuration of the targets.

SCEP 11	SCEP 11
Parameters For SCEP       SCEP Server's URL:       Encryption:       DES       Y   Signature: SHA1 *	Parameters For SCEP       SCEP Server's URL:       http://CAServer/certsrv/mscep/mscep.dll       Encryption:     3DES       *     Signature:       SHA1     *
Import certificates for RA and CA	Import certificates for RA and CA
Import enrollment certificate (Mandatory) EMPTY	Import enrollment certificate (Mandatory) PRESENT
Import enciphernment certificate (Mandatory) EMPTY	Import enciphernment certificate (Mandatory) PRESENT

# 6.2.4 Telephony

## 6.2.4.1 Localisation

The localisation options are used by various modules within the firmware and **must** correspond to the locale where the system is installed and operated from.

Localisation 🛛		
NationalPrefix	0	
InternationalPrefix	00	
CountryCode	49	
Tones	Germany	-

• National prefix

The digit(s) that are required to be dialed for national numbers, for example in Germany 0'' is the prefix that signifies a national number.

• International prefix

The digit(s) that are required to be dialed for international numbers, for example in Germany "00" is the prefix that signifies an international number.

• Country code

The digit(s) of the country, in which the NMG is installed. If the NMG is installed in Germany, the digits would be 49 (without the leading zero's). In the UK this would be 44.

• Tones

The system can generate the required tones normally provided by the network provider (alerting etc.).

#### 6.2.4.2 **VoIP**

#### 6.2.4.2.1 SIP

#### 6.2.4.2.1.1.1 SIP Codec Mapping

Version 1.1 (final Version)



In this section, you can change the default behavior of the NovaTec system regarding the mapping of codecs. This is very useful when "exotic" or manufacturer defined codecs are implemented by different systems, but could be used with the existing codecs installed on the NovaTec system using slightly different standard settings. Changing the settings, as shown here, can have a serious detrimental effect on the stability and functionality of the system!

SIP Codec Mappings 🛛					
Payload	Mapped to				
8	G711_aLaw				
0	G711_aLaw				
125	G711_aLaw				
18	G729_AB				
114	G_726_40				
127	G_722_1_32				
9	G_722_64				
97	ilbC				
	Payload 8 0 125 18 114 127 9 9				

Dependent on the codec set which is currently active, the display may differ slightly from what is seen on a normal The standard codecs are automatically "mapped" to the codec (i.e. themselves). User defined codecs can be here, and then mapped to a codec that is installed on the system.

Codec properties		
Name:		
Payload:	0 *	
Clock:	Unused 👻	
Optional extensions:		
FMTP:		above
RTP packet time (ms):	10 *	system.
Туре:	audio	correct
Description		aroated
Can be used for tra	nsparent calls	
Bearer capability:	User defined 👻	Novalec
Calling subaddress:		
Called subaddress:		
Map to the codec:	G711 aLaw 🔻	followc
	Ok Cancel	TOHOWS.
	OK CONCE	priority list

The priority of the selected codecs can be changed as

Click on the selected codec and drag it up or down in the with the mouse.

#### To create a new codec:

Right-click into the window "SIP Codec Mappings" and select "Add" from the pop up menu. Then edit the required parameter:

• Name

The name of the codec which is going to be used.

• Payload

The numerical RTP payload type.

Clock

The clock settings for this codec. It is recommended not to change this value.

• FMTP

The FMTP setting for this codec. This value indicates which named events a codec can handle. For more information please read the Session Description Protocol (RFC 2327 [7]) It is recommended not to change this value.

RTP packet time (ms)



This value defines the length of time (Packet time) in milliseconds represented by the media in a packet. It is recommended not to change this value.

• Type

The type of this codec. This is an internal value used by the NMG system to identify the codec type. Possible values are: audio, DTMF, fax and video. It is recommended not to change this value. Standard is audio.



• Description

The informational description for this codec. This value is used internally for informational purposes only. It must not be left empty.

• Can be used for transparent calls

When activated, this allows the NMG to use this codec for transparent (data or fax) calls. It is recommended that at least one codec has this flag set.

The following fields are inserted into the codec properties verbatim. If you have not been asked to enter anything here, or are not sure, DO NOT CHANGE ANY OF THESE SETTINGS!

• Bearer capability

The bearer capability of this codec.

• Calling sub address

The SubSrc property of this codec.

Called sub address

The SubDst property of this codec.

• Map to the codec...

This codec is currently mapped to the codec displayed in the combo box (if any).

To change or edit a codec:

Right-click the codec which has to be changed in the list under "Sip Codec Mappings". A pop up menu appears. Select "Edit" and then make the required changes.

					Codec properties		
					Name:	pcma	
					Payload:	8	
					Clock:	8000	*
					Optional extensions:		
_					FMTP:		
	SIP Codec Mappings 🛛				RTP packet time (ms):	20	*
	Description	Payload	Mapped to		Туре:	audio	Ŧ
	al aw 64kbit/s MOS 4.4	8	G711 allaw	_	Description:	aLaw 64kbit/s MOS 4,4	
	ul aw 56kbit/s MOS 4 2	0	G711_uLaw	Add	Can be used for tra	ansparent calls	
			G/II_dEdw	Edit	Do not use for voic	e calls	
	CISCO X-CCD	125	G/11_aLaw	Remove	Bearer capability:	User defined	*
	G729A,B 8kb/s MOS 4,0	18	G729_AB				_
	iLBC 13,3 - 15,2kbit/s MOS4	97	ilbC				
	telephone-event	101	DTMF		Calling subaddress:		
	G726 40kbit/s MOS 4.0	114	G_726_40		Called subaddress:		
	G.722.1 32kbit/s MOS 4,3	105	G_722_1_32		Map to the codec:	G711_aLaw	*
	G722 64kbit/s MOS 4,4	9	G_722_64			Ok Cancel	

To remove a codec proceed as follows:

Right-click the codec which has to be removed in the list under "Sip Codec Mappings". A pop up menu appears. Select "Remove".





#### 6.2.4.2.1.2 Global SIP Options

In this chapter you will find a description on how to set the global options for the SIP applications of the targets:

General settings

General settings			
Session owner:	Sess_Owner	Session name:	Sess_Name
Anonymous name:	Ano_Name		

• Session owner

The session owner of the SIP session. This value is used between systems for administration purposes. Please note that this value should not contain any spaces.

• Session name

The session name. This value is for informational purposes only.

• Anonymous name

Standard name to identify the system under CLIR conditions.

• Feature options

#### If ticked

- Register as Cisco device at UCM If the target needs to register as a line / phone.
- Support IETF drafts

Should preliminary IEFT extensions (which are standard de facto) be supported.

• Support proprietary SIP plus

Support the incomplete number processing. This option is currently not recommended.

• Activate SIP bridging

The signaling runs via the CCU, the RTP stream between SIP trunks or SIP subscribers.

Support PRACK

Support extensions (100rels) to SIP.

Support 484 incomplete number

Support the incomplete number processing. This option is currently not recommended.

• SDP options
#### Version 1.1 (final Version)



SDP options	
✓ Negotiate telephone events 32 to 35 ANS and ANSAM	Do not detect DTMF payload type change
Do not repeat SDP after early media	Do not detect obsolete voice codecs

#### If ticked

• Negotiate telephone events 32 to 35 ANS and ANSAM

If the flag is disabled, the gateway will enable telephone events per default (tone detection and generation in RTP/SRTP) for ANS and ANSAM tones even if the SIP counterpart does not signal support for it during SIP SDP/codec negotiation. If the flag is enabled, the ANS and ANSAM telephone events will only be activated if the SIP counterpart does signal support for it.

• Do not repeat SDP after early media

Some remote systems (i.e. the third party software) may 'loose' the signaled RTP parameters, that were provided with the 'early media' (18x), while processing the connect response (200). This flag allows resending SDP with the 200 (connect) response. It is recommended to set this option.

Do not detect DTMF payload type change

Automatically detect any changes in the poorly specified DTMF payload type, during session communication.

• Do not detect obsolete voice codecs

This option allows to avoid a codec agreement only upon the payload type number. If the parameter is set, the codec names will be compared (case insensitive) as well. Some third party software uses old payload type numbers for some archaic codecs.

RTP settings

IP port start:     30000     IP port stop:     30254     IP       Disable codec filtering     IP     IP     IP	RTP settings			
Disable codec filtering	IP port start:	30000 🌻	IP port stop:	30254
	Disable codec filter	ring		

• IP port start/IP port stop

Defines the range of the port numbers to be used for VoIP. **Attention:** The Port range should not be smaller than the number of the selected Codecs.

• Disable codec filtering

With this box the codec filter can be switched on or off.

In case the filter has not been disabled, the Codec will be negotiated between the VoIP partners.

• Session timers RFC4028

✓ Support timer       Min session expire (s):     1800     ↓     Session expire (s):     28800     ↓	Session timers RFC4028				 
Min session expire (s): 1800 + Session expire (s): 28800 +	Support timer				
	Min session expire (s):	1800	Session expire (s):	28800	

If ticked

Support timer

Try to arbitrate the session renewal using the "timer" utility/extension to SIP.



While having this ('keep alive') extension active, the session must be renewed automatically from either a server, or a client.

The other fixed session expire timeouts ('Expire time for active calls') will not be applied in this case.

• Min session expire (s)

A value that will be used during arbitration of the "timer" utility/extension to SIP. Please refer to RFC for this parameter. The standard value is recommended.

• Session expire (s)

A value that will be used during arbitration of the "timer" utility/extension to SIP. Please refer to RFC for this parameter. The standard value is recommended.

• Refer method RFC3515

REFER method RFC3515	
Ignore external REFER Cctr	Obey external blind call transfer
Execute call transfer with REFER method	

# If ticked

• Ignore external REFER Cctr

Explicitly ignore an external 'consultative' call transfer (CCTR) with REFER, as the provided destination numbers or the call transfer itself via SIP might be unwished.

• Execute call transfer with REFER method

If this flag is disabled, the gateway will perform a call transfer by internally through-connecting the two parties. After the call transfer the new resulting call will still use the gateway/resources in the gateway.

If the flag is enabled, the gateway will send a SIP REFER message on call transfer to instruct the SIP counterpart (e.g. a Cisco UCM) to perform the call transfer in the network. After the call transfer the new resulting call bypasses the gateway completely and all previously occupied resources are freed immediately after the transfer (channels, codecs/DSP resources and memory).

• Obey external blind call transfer

Explicitly enable an externally provided 'blind' call transfer (BCTR) with REFER, as the provided destination numbers or the call transfer itself via SIP might be unwanted.

• Symmetric response routing RFC3581

Symmetric respon	se routing RFC3581		
Use R por	Support received		

If ticked

• Use R port

'rport' is a diagnostic parameter used in SIP transport lines ("Via:" header). Please refer to RFC about details. The response to 'rport' provides the own IP send port values as seen from the remote side. It



allows to diagnose some transport related issues (like NAT). The option is irrelevant except for the system managers in certain trouble shooting scenarios.

• Support received

'Received' is a diagnostic parameter used in SIP transport lines ("Via:" header). Please refer to RFC about details. The IP address values will be returned with 'Received' to the requester. It allows to diagnose some transport related issues (like NAT). The option is irrelevant except for the system managers in certain trouble shooting scenarios.

• Global addressing options

Global adressing option	5		
External gateway IP	)		
IPv4 address:			
IPv6 address:			
External name:			
VPN mask:			
Use local nan	ne		
Insert plus for	international numbers	No IP address	s verification
Accept dereg	istered destination if address	known 🗹 Replace loca	al numbers with avaiable outbound maps
Allow change	of invalid SIP addresses		

# If ticked

• IPv4 address

The external IPv4-Address of the firewall/router. This is the address of the gateway seen from outside of the internet.

IPv6 address

The external IPv46-Address of the firewall/router. This is the address of the gateway seen from outside of the internet.

• External name

The external domain name.

• VPN mask

The IP-Address of this system used in a "Virtual Private Network".

Use local name

Use the domain name (respectively alias name if supplied), to identify itself. If not supplied, use the system IP address.

• Insert plus for international numbers

Insert automatically the '+' for international numbers.

• Accept deregistered destination if address known

Route to deregistered destination addresses if the address is statically assigned.

Allow change of invalid SIP address

NMG software follows a very tight security policy. The SIP packets are verified, whether they are tempered, faked or malformed. Especially the IP addresses are verified against the registration (account)



data. Some third party software provides, for example LAN IP addresses in public transport lines. SIP requests from such counterparts will be discarded. This parameter allows to 'switch on' a 'softer' policy. In this case the option 'Correct faulty format' may be applied individually to the entries in the 'user mappings'.

- No IP address verification
- Replace local numbers with available outbound maps

The 'local mappings', which result in a registration on external servers, will be always inserted to the 'reverse local map'. The 'reverse local map' creates a reference between the local subscriber number and his identity at the external server (registrar). The flag forces creating the reverse references to all local subscriber numbers, so that the externally presented name or number will result from the reverse map.

• Routing options



• Allow direct SIP routing

If ticked, it allows the direct routing of SIP to SIP calls without passing through the Layer 3 administration modules (not recommended).

• Performance options

_	Dedamara after
	renumance oppons
	Establish TLS connection queue
L	

#### If ticked

• Establish TLS connection queue

To avoid system overload if too many TLS linkups are expected at the same time after system restart, this queue can be activated.

Security options

Security options	
Do not ignore unauthorized sites	Do not use authorization

• Do not ignore unauthorized sites

Authorization is enabled by default and unauthorized sites are ignored to prevent / minimize the risk of DoS attacks. Checking this option is not recommended, a site which has no authorization to use this NMG, would then receive a reply stating.

• Do not use authorization

Account and password are not verified when logging in.



#### • Signaling options

Signalling options
Use to header uri instead of request URI Add no optional at host ip to the call ID
Ignore always every received contact field 📃 Use Received Contact Only With At

- Use to header uri instead of request URI If checked, the "To:" header field ids used instead of the INVITE request URI in the SIP protocol.
- Ignore always every received contact field The address in the field "contact" of the received SIP session will not be included into the URI of the following SIP sessions.
- Add no optional at host ip to the call ID

Adds the call ID to the end of an outgoing SIP session.

@IP-Adresse: bilioew-gnv-uyefybqbrutfgi@192.169.40.162

Without: bilioew-gnv-uyefybqbrutfgi

• Use Received Contact Only With At

Similar to "Ignore always every received contact field".

If there is no IP address or hostname provided in the received contact field, the content will not be included as URI in the following SIP sessions.

• ISDN GW options

ISDN GW options		-	
Send progress	None 🔻		
		SIP Timeout Options 🛛	
Canadamana		Call setup timeout (s):	102
<ul> <li>Sena progress</li> </ul>		Repeat interval (ms):	500
The progress indication	ion will be sent (in the ISDN	Maximal number of repeats:	0
lea)	Ϋ́Υ.	Ping time (s, 0 = disabled):	0
iegy:		Disconnect wait (s):	10
Indication type		Expire time for active calls (s):	28800
Destination is non IS	N	System session timeout (s) MUST > Expire time:	86400
		Time limit to cache DNS resolutions (s):	86400
The terminal is not I	SDN equipment.	Maximum number of retries to resolve an address (s):	0
Call is not End to Er	nd″	Backoff time for unresolved name:	0
		DNS request timeout:	0
This option indicates	that the call is passing through	URI SIP resolution timeout:	0
a non ISDN network		Registration Expire Time:	0
		Public registration expire time:	300
		Proxy link expire time:	180
		Inter digit timer delay (s):	0
6.2.4.2.1.3 SIP Ti	meout Options	Fake alerting timer delay (s):	7
Here the various timeout o	ntions are set for the SIP	Wait for alert timer delay (s):	0
application running on the	System These timeouts are set	Wait for connect timer delay (s):	0
		Wait for release timer delay (c):	A 4

Wait for release complete timer delay (s):

Disconnect tone duration (s):

application running on the System. These timeouts are set to standard values, which by default should work with the various environments that the NMG could be used in.

• Call setup timeout (s)



The Call setup timeout for outgoing SIP calls.

• Repeat interval (ms)

The interval between Call setup attempts to the ISDN network.

• Maximal number of repeats

The maximal number of attempts to route / contact the ISDN network (call setup).

• Ping time

Time between each "ping" sent to ensure that the session is still valid (0 = disabled).

• Disconnect wait (s)

The time that the system will wait before automatically disconnecting any calls that may not have been cleared correctly.

• Expire time for active calls (s)

The maximal time that a SIP call may be active (prevents unnecessary IP traffic and use in the case of SIP errors during the disconnect stage).

• System session timeout (s) Must > Expire time

The maximal time that a single session may be active for. This time MUST BE larger than the Expire time for active calls.

• Time limit to cache DNS resolutions (s)

The time limit that is used before any DNS cache entries are cleared (cache flushing).

• Maximum number of retries to resolve an address (s)

The maximal number of attempts to resolve an address to it's ISDN counterpart.

• Back off for unresolved name

The time span between unsuccessful attempts to resolve an address/name.

• DNS request timeout

The timeout for DNS requests.

• URI SIP resolution timeout

The timeout before unsuccessfully SIP resolution actions are accounted as failed.

• Registration Expire Time

The expire time which this NMG uses to register at an external system.

• Public registration expire time

The expire time which this NMG uses to register at a public external system.

• Proxy link expire time

The time interval used internally by the NMG, to keep temporary information. Please leave this value unchanged, unless the NovaTec support team recommends using another value.

• Inter digit timer delay (s)

Automatically clear the call, after the number of seconds entered here, once the called party has hung up.

• Fake alerting timer delay (s)

The NMG will "fake" the alerting signal, when the network / user has not responded to the call setup within the time here. The tone type is set here.



- Wait for alert timer delay (s) The maximal waiting time for the ALERT signal before aborting the call.
- Wait for connect timer delay (s) The maximal waiting time for the CONNECT signal before aborting the call.
- Wait for release timer delay (s) The maximal waiting time for the RELEASE signal, before carrying out normal call clearing.
- Wait for release complete timer delay (s) The maximal waiting time for the RELEASE COMPLETE signal, before carrying out normal call clearing.
- Disconnect tone duration (s)
   Automatically clear the call, after the number of seconds entered here, once the called party has hung up.

# 6.2.4.2.1.4 Trunks

This chapter explains the special settings for a configuration of an SIP trunk to a Cisco CUCM.

Any other partner but CUCM does not need these special settings.

Click on trunk. The following window appears:

ame	IP   Domain   SIP	Number	Voice profile	Data profile

To create trunk(s) right-click into the section "Trunks" and select "ADD" from the pop up menu. Enter the exact parameter of the trunk.

Each entry or trunk can be edited (Edit) or removed (Remove) with a click onto corresponding trunk with the right mouse button.

me	IP   Domain   SIP	Number	Voice profile	Data profile
		Add		
		Edit		
		Remove		

The window SIP trunk appears:

Name:	Number:	
CUCM trunk	Enable call forw	varding in network

Name

Edit any name for the trunk like publisher or subscriber etc.

Number



Head number of the trunk line

CUCM trunk

This option does not need to be activated, if the option "Ping of the SIP Trunks within the CUCM configuration" has been activated.

• Enable call forwarding in network

Call forwarding will be done on the remote end when enabled.

• Device options

Device op	tions				
Device:	Phone	Ŧ			
Sub:			LLC:		
BC:	User defined	•	HLC:	User defined	*

Device

Select the device for this user. Valid devices are phone, facsimile, modem or combined device.

• Sub

Enter here the sub address information element.

• BC

Select here the bearer capability of this user.

• LLC

Enter here the low layer compatibility information element.

• HLC

Select here the high layer compatibility of this user.

• T38 Settings

This function will be implemented in a higher / later version of NAMES.

Start T38 on detection of			
DIS-IP CNG-IP CED-IP	CNG-Fax		
Remote behaviour after fax	No transport codec reinvite with:		]
Fallback to audio if remote no T38	1	L '	_

• Use Fax over IP/T.38

Check this option to enable or disable the T.38 functionality.



It is recommended to prioritize the transparent voice codecs (for example: pcm-aLaw, pcm-uLaw,...) higher than non-transparent voice codecs to increase the likelihood to send a fax to non T.38 enabled devices.

- DIS-IP
  - Digital Identification Signal (over IP)
- CNG-IP
  - Calling tone (over IP)
- CED-IP
   Called Terminal Identication (over IP)
- CNG-Fax Calling Tone (from own facsimile)
- Remote behavior after fax If this option is disabled, the system closes the connection after completion of fax-transfer.

By activation of this option, the system depends on the remote side behaviour, i.e. the remote side decides to close or not to close the connection.

- Fallback to audio if remote no T38
   If the remote side does not support T.38, normally the T.38 connection would be closed.
   After activation of this flag, if the remote side does not support T.38, the system tries to "fall-back" to audio, i.e. the system tries to use a transparent codec (negotiated at the first session establishment) to establish a T.38 connection.
- No transport codec reinvite with

If at the initial session establishment no transparent codec was negotiated and the system tries to send a facsimile, you can choose to re-invite with a new negotiated transparent-codec or direct with the T.38 protocol.

Address settings

Address settings			1
URI:			
IP service:	UDP	v	
Correct faulty format Public access Can	redirect in LAN		
			URI

The URI, user name or IP address.

• IP service

There are three protocols to choose from, depending on the type of service required. The three protocols are: UDP, TCP and TLS.

- Correct faulty format If this option is checked, then faulty/incomplete IP addresses will be accepted.
- Public access

If this option is checked, public access is allowed

• Can redirect in LAN

If this option is checked, a direct connection within a LAN is preferred (answer with 305/reflection if both SIP devices flagged and in LAN).



• Codec negotiation settings

Codec negotiation settings						
Pref. voice codec:	Any (negotiate)	*	Pref. data codec:	Any (negotiate)	*	

• Pref. Voice codec/ Pref. data codec

The preferred voice and data codecs to be used for this user. These options can be used to "force" a specific user to use specific codecs contrary to the standard codec negotiation settings.

• Account settings

Account settings					
SRTP mode:	Do not use	RTP timeout:	0	* *	
VoIP port profile voice:		VoIP port profile data:			*

• SRTP mode

Here, the encryption mode can be set. Possible values are:

- Do not use Encryption should not be used for this user.
- Try to use

Encryption should be used for this user as default, however if no encryption capability is available (either on this system, or the called party) the call will be made anyway.

Must use

Encryption must be used by this user. If no encryption capability is available (either on this system, or the called party) the call will not be completed.

• VoIP port profile voice/ VoIP port profile data

In this section, the profiles that may have been created in VoIP port profiles, are assigned to the available SIP interfaces and define the default behaviour of these interfaces. If you have not created any port profiles, the standard port profile is automatically assigned to the available interfaces. If you delete a profile, which was previously assigned to an interface, the standard profile is automatically re-assigned to the interface(s).

RTP timeout

The time (in milli seconds) to be used for the SIP packet time encoding.

Minimal number of digits:	Disable early media for voice
Disable early media for data	

- Minimal number of digits Here the minimal number of digits is set. This number represents the minimal number of digits that will be cached, before the number is considered to be complete, and the Call setup will be carried out.
- Disable early media for data



If this option is checked, then the EARLY MEDIA event is sent for data calls. This of course incurs traffic over the RTP stream, which in some cases may not be desirable. If this is the case, the EARLY MEDIA event can be de-activated (checking the option).

• Disable early media for voice If this option is not checked, then the EARLY MEDIA event is sent for voice calls. This of course incurs traffic over the RTP stream, which in some cases may not be desirable. If this is the case, the EARLY MEDIA event can be de-activated (checking the option). The standard setting is activated.

# 6.2.4.2.2 NAT

The System NAT mapping is the configuration page to set up the NMG system when working behind a firewall/router and a connection is required to the internet. Most notably for the NIP, VSMSC, and SIM server-SIM client applications. Various modules / applications use these settings. It is advisable to make changes here with the help of the Network Administrator to avoid any problems.

Click on "NAT". The following window appears:

rotocol	Own IP	Own port	External IP	External port	
			Add		
			Add		

To create a NAT mapping, right-click into the NAT window. The Following window appears: NAT Mapping

Protocol

The protocol can be set to UDP or TCP.

• IP

The RTP-IP address can be found on CCU. • Own IP/Address

- The IP address can be found on the CCU.
- Port

The internal port has to be mapped.

• External IP/Address

This is where the IP address of the firewall would be entered. If this box is left blank (or filled with zero's), the standard IP address or the domain name will be used (if entered).

NAT Mapping

Protocol:

UDP

IP:

IP/Address:

Port:

IP/Address:

Port:

Ok

Cancel

• Port

The port that is to be mapped to. This must be set, so that any request / connections to the firewall on this port are forwarded to the IP address port as set in the second column. As mentioned previously, these settings should be made with the help of the Network Administrator.

# 6.2.4.2.3 STUN

STUN enables a device to find out its public IP address and the type of NAT service its sitting behind. STUN operates on TCP and UDP port 3478. STUN and NAT have not been defined for IPv6, because none of them is necessary in IPv6 network.

```
DB.NAMESMAN30.NT
```



- STUN
  - Mode

Three settings are available: Off, Server and Client.

**STUN Client:** A STUN client (also just referred to as a client) is an entity that generates STUN requests. A STUN client can execute on an end system, such as a user's PC, or can run in a network element, such as a conferencing server.

STUN 8		
Mode:	Off	Ŧ
Own port:		
Remote server IP:		
Remote server name:		
Remote port:		

**STUN Server:** A STUN Server (also just referred to as a server) is an entity that receives STUN requests, and sends STUN responses. STUN servers are generally attached to the public Internet.

Own port

The port on which the service will be sending on.

- Remote server IP The IP address of the remote machine / service that this service is to connect to. This value is only applicable if this service is a **client**.
- Remote server name The (domain) name of the remote machine / service that this service is to connect to. This value is only applicable if this service is a **client**.
- Remote port The port on which the service will be receiving on, for example 3478 for STUN.

# 6.2.4.3 **ISDN**

# 6.2.4.3.1 Trunks

This section explains how to provide an ISDN trunk to a second party PABX, PSTN line or gateway. The ISDN Trunk can be created in master or slave mode.

Click on "Trunk". The following window appears:

Trunks 🕮						
Name	Mode	Number	Interfaces			

To create an ISDN trunk right-click in the section "Trunk" and then onto "Add" in the pop up menu. In the window opening up you can remove, edit or fill in the required parameter of the trunk system.

Trunks 😫				
Name	Mode	Number	Interfaces	
	Add			
	Edit	1		
	Remove			

The window "ISDN Trunk" appears:



ISDN Tru	ink			$\otimes$
Name:			Number:	
Mode:	Round Robin	•		

- ISDN Trunk
  - Name

Any name can be used for the trunk.

- Mode
  - Round-robin

For each call that comes to this trunk, the next interface will be used for that call. For example, there are four interfaces assigned to this trunk, 1, 2, 3 and 4. The last call that came to this trunk was sent to interface 2, therefore, the next call will be sent to interface 3, the next to interface 4 .... This mode of operation ensures that all interfaces within a trunk are evenly used.

Sequential

In this mode of operation, each interface in the trunk is used in order, i.e. if of the four interfaces assigned to this trunk, interface 1 is in use, then the next call will be sent to interface 2, if in the meantime the call using interface 1 has been completed, and another call comes in on this trunk, then it will use interface 1, as it is free.

Number

Head number of the trunks

The next step is to setup the interfaces of the trunk: Right-click into the section "Interfaces" and select "Add" from the pop up menu to edit the local parameter. All entries regarding the trunk can be changed by selecting "Edit" or deleted by selecting "Remove" instead of "Add".

Name		
	Add	
	Edit	
	Pamova	

After selecting "Add", the following window appears:

ISDN Trunk	Interface		$\otimes$
Name: Type:	DSS1	•	
Mode: AOC enc	oding:	Config:	T
		Ok Cancel	

Version 1.1 (final Version)



<ul> <li>S21</li> <li>Slot 1   CCU4</li> <li>Number of VoIP codecs: 128</li> <li>Board 1   S04</li> <li>ISDN Interface 1   Active  , Master</li> <li>ISDN Interface 2   Active  , Master</li> <li>ISDN Interface 4   Active  , Master</li> <li>Board 2   S2M2</li> <li>ISDN Interface 1   Active  , Master</li> <li>ISDN Interface 2   Active  , Master</li> <li>Slot 2   CAU2</li> <li>Slot 3   Empty</li> <li>Slot 4   Empty</li> <li>Slot 6   Empty</li> </ul>	ISDN Trunk Interface         Name:         Type:       DSS1         Mode:          • Config:         AOC encoding:          • Config:         Ok       Cancel	
---	---	--

Press " — " and choose the available interfaces in the opening window to assign them to the corresponding trunk:

After choosing the required interface press button "Ok".

lame:	Slot	1 (CCU4) Subm. 1	(S04			
Гуре:	DSS:	L	-			
Mode:		TE		Config:	PTP	
AOC end	oding:	Currency				

The selected interface appears in the box "Name". Further settings are necessary:

- Type
  - DSS1
  - QSIG
- Mode
  - ΤE
  - NT
- Config

PTP -> Point to point connection with TEI=0 (for example PABX Trunks) PTMP -> Point to multi point connection (up to 50 MSNs possible)

- AOC encoding
  - Currency If AOC information needs to be generated by the target, it will be sent as currency.
  - Units

If AOC information needs to be generated by the target, it will be sent as units.



Outgoing calls can be distributed between the interfaces of a trunk by the system in a given sequence. The sequence can be changed by dragging the appropriate interface up or down within the list of interfaces.

# 6.2.4.4 Call Routing

This chapter describes how to create trunk groups, subscriber groups and line groups and the setup of routings between them.

The first step is to create the trunk group:

# 6.2.4.4.1 Trunk groups

# 6.2.4.4.1.1 New Trunk Group

Click on call routing and the following window will appear. Right-click onto "Trunk Group" and then onto "New Trunk Group" in the pop up menu.



The following window appears:

Trunk Group		$\otimes$
Name: Trunk-1		
Ok	Cancel	

Enter a name for the trunk group (here Trunk-1). Click on Ok. The following window appears:



In the new window the new trunk group (here Trunk-1) is now visible. For further settings simply click onto Trunk-1 and following window appears:

# Version 1.1 (final Version)



Call Routing 🛛	
Trunk groups Trunk-1 All subscribers Line groups ALCR	Allowed destinations
	Allowed sources
	Call data recording Call data profile: Price per charge unit:
	Mode: Round Robin   Always connect channel early
	Referenced bunks
	Trunk name Type

• The box "Allowed destination":

Is for all destinations like subscribers of the system itself.

• The box "Allowed sources":

Is for all outer destinations.

- Section Call data recording
  - Call data profile

Is a selection of the profiles which have been created as call data profiles before (See chapter 6.2.4.8).

• Price per charge unit

The unit cost of the trunk line in the local currency can be entered here. It is advisable to enter the value of 0.01 here for internally generated unit charges. This value must also be entered on the subscriber's terminal equipment. For externally generated unit charges, enter the trunk line standard price i.e the price per unit of the provider.

- Mode
  - Round Robin

For each call that comes to this trunk group, the next interface will be used for that call. For example, there are four interfaces assigned to this trunk group, 1, 2, 3 and 4. The last call that came to this trunk group was sent to interface 2, therefore, the next call will be sent to interface 3, the next to interface 4 ....

This mode of operation ensures that all interfaces within a trunk group are evenly used.

Sequential



In this mode of operation, each interface in the trunk group is used in order, i.e. if of the four interfaces assigned to this trunk group, interface 1 is in use, the next call will be sent to interface 2, if in the meantime the call using interface 1 has been completed and another call comes in on this trunk group, it will use interface 1, as it is free.

This method is not recommended for use in trunk groups that have GSM interfaces assigned to it, as the SIMs used by the interfaces will not be evenly used.

• Always connect channel early

If this option is activated, the NovaTec gateway will always connect the b-channel through when the call is alerting even if the called PBX does not signal/indicate the presence of a ring back tone. This is the default setting and matches the behaviour of previous firmware versions.

If the option is deactivated, the NovaTec gateway will play its own ring back tone when the call is alerting and the PBX does not signal/indicate the presence of a ring back tone.

Referenced trunks

All trunk groups listed here (SIP or ISDN) will receive the same sequence mode as selected under top down menu of mode. The sequence can be changed by select and pull function with a click onto the trunk group.

• Number Modification

Number modifications are optional and can be created to modify or change the parameters like calling number of a call session. Also during routing of a call the prefix of a calling number can be removed or the configured head number of the trunk inserted. Generally for major number masquerading, the number modification can be used.

A number modification entry contains two parts: One part is called "Match" and the second is called "Action". The "Action" part determines, what and how is changed (for example: Add a prefix to the calling number or cut off a part of the caller number). The "Match" part determines under which circumstances the corresponding action is executed. For example: Under all circumstances or only for inbound calls or if the caller number has got a certain TON (Type of number).

Right-click into the window and select "Add" from the pop up menu. The following window appears:

Match	Action
	Add
	Edit
	Remove

- Match
  - Always (If checked)
  - Direction (defines in which direction the "Action" is executed "inbound" or "outbound" calls )
  - Both

(defines, that the "Action" is executed in both directions - "inbound" and "outbound" calls)

- Incoming Execute the "Action" only for inbound calls.
- Outgoing Execute the "Action" only for outbound calls.
- Calling number

Execute the "Action" only when the caller number is identical to the included prefix in the match list. In case there is no entry in the match list, the "Action" will be executed regardless of the caller number.



- Called number Execute the "Action" only when the calling number is identical to the included prefix in the match list. In case there is no entry in the match list, the "Action" will be executed regardless of the calling number.
- Calling TON
   Execute the "Action" only when the TON (Type of number) of the caller number is identical to the included TON in the match list. If there is no entry in the match list, the "Action" will be executed regardless of the TON of the caller number.
- Called TON

Execute the "Action" only if the TON (Type Of Number) of the calling number is identical to the included prefix in the match list. In case there is no entry in the match list, the "Action" will be executed regardless of the TON of the calling number.

All corresponding sectors under "Match" will be operated as an "AND Operation", if more than one sector has been filled out. If for example a value has been edited under direction and calling number the call route and the calling number must be equal to the included values to execute the appropriate "Action".

Match			
Always			
Direction:	×.	Calling number:	
Called number:		Calling TON:	•
Called TON:	•		

Calling number	
Set TON:	▼ Set NPI:
AddPrefix:	DelPrefix:
Add Suffix:	DelSuffix:
Insert	
At position:	Digits:
Cut	
At position:	Count:
Set	
Digits:	



Called number		
Set TON:	• Set NPI:	*
AddPrefix:	DelPrefix:	
AddSuffix:	DelSuffix:	
Insert		
At position:	Digits:	
Cut		
At position:	Count:	
Set		
Digits:		
Calling name		
Set:		

- Action (what is to be executed?)
  - Calling Number

All entries in these boxes of the group will change the calling number:

- Set TON: Change the type of number to the entered value!
- Set NPI: Change the numbering plan identification NPI like ISDN, data etc. to the entered value!
- $\circ$  AddPrefix: Insert the following digits at the beginning of the number.
- DelPrefix: Delete the following digits from the beginning of the number (only at match).
- $\circ$   $\;$  AddSuffix: Insert the following digits at the end of the number.
- $\circ$   $\;$  DelSuffix: Delete the following digits from the end of the number.
- $_{\odot}$   $\,$  Insert: Insert the following digits at the given position in the string of the number.
- $\circ$  Cut: Delete the following number of digits from the given position in the string of the number.
- Set: Exchange the whole number against the one following.
- Called Number

All entries into the boxes of this group will change the called number. The boxes for these settings are the same as for the calling number.

Calling Name

Change the calling name.

 $\circ$   $\;$  Set: Set the calling name to the entered value.

# 6.2.4.4.1.1.1 New Number Group

For the new created trunk group (here Trunk-1) a new number group and/or new number can be set. First a number group must be created: Right-click on "Trunk-1" and select "New Number Group" from the menu. In the following the settings for a new number are explained:



Copyright 2017 NovaTec Kommunikationstechnik GmbH

Version 1.1 (final Version)



The following window appears:

Number group 🛞	Number group	$\otimes$
Name:	Name: Number-1	
Ok Cancel	Ok Cancel	

The number group can be named in the correlating window "Number group". After clicking onto Ok, this given name appears under Trunk-1 (see following picture, here Number-1). In this number group single numbers or number ranges can be entered. For example the subscriber can setup an outbound call on Trunk-1 with this number group.

<ul> <li>Trunk groups</li> </ul>	
Trunk-1	
Number-1	

Version 1.1 (final Version)



Click onto Number-1. The following window appears:

Name		Туре	Number/Prefix	Remove Prefix
Allowed Sources				
Туре	Name			
Definition				
Definition	Туре			
Definition ) refinition	Туре			

To enter a single number or a range of numbers right-click under "Definition" and then select "Add" in the pop up menu. The following window appears:

Definition 🛞	Definition	$\otimes$
Definition: Number -	Definition: Range +	
Number: Exclude	Start: End:	Exclude
Ok Cancel	Ok Cancel	

Definition

Is a drop down menu to adjust whether you are defining a number or a range of numbers.

• Number

After selecting "Number" only one prefix should be included to assign a trunk.

Range

If "Range" is selected, a range of numbers (for example Start:0 and End: 9) can be defined to assign a trunk.

• Exclude

If this box is ticked, the corresponding number or range of numbers is blocked and cannot assign this trunk.

It is also possible that two number ranges overlap. For example one range can start with the digit "3" and end on "9", whilst the range from "31" to "32" within the above mentioned range is blocked.



Definition	Туре
21	Number
0 - 1	Range
22 - 29	Range
3 - 9	Range
31 - 32, barred	Range
20, barred	Number

# 6.2.4.4.1.1.2 New Number

To create a new number, right-click TRUNK-1 and select "New Number":



The following window appears:

Named number		$\otimes$
Name:	Number:	
	Ok Cancel	

The name of the owner of the number should be entered under "NAME" and the corresponding number under "Number" (see below picture) and confirmed with Ok. The owner name will appear under Trunk-1/ Number-1.

Named number 🛞		
Name: Handy Hr. Meier Number: 0160123456789	<ul> <li>Trunk groups</li> <li>Trunk-1</li> </ul>	Number: 0160123456789
Ok Cancel	Number-1 Handy Hr. Meier	

The named number can also be used for routing (subscriber, line group, trunk group and call data profile). All settings under trunk groups can be changed, edited or removed.

# 6.2.4.4.2 All subscribers

All settings of every subscriber are gathered under all subscribers. Here one or more subscribers can be combined to a subscriber group and all subscriber groups are subordinated to the item "All subscribers". Settings made under "All subscribers" are inherited by all subscriber groups. Settings made within a subscriber group are inherited by all subscribers of that group. Here also permissions can be granted. Simply click the

permissions you want to grant to do so. A green tick 🧭 appears. In order to withdraw permission you only need to click it anew. Permissions granted here are valid for subscriber groups and subscriber.



anic	1 y Pr	3	Number/Prenx	Remove Prenx
Allowed Sources				
Туре	Name			
Permissions	Call Forwarding	Co Hold		Explicit call transfer
Permissions Short Code Dialing	Call Forwarding	Co Hold		Explicit call transfer
Permissions Short Code Dialing Call take over	Call Forwarding	Hold		Explicit call transfer
Permissions Short Code Dialing	Call Forwarding	Hold		Explicit call transfer
Permissions Call take over Permissions Short Code Dialing	Call Forwarding Advice of charge	Image: Control of the second secon		Explicit call transfer MLPP
Permissions Short Code Dialing Call take over Permissions Short Code Dialing Call take over	Call Forwarding Call Forwarding Call Forwarding Call Forwarding Call Forwarding	<ul> <li>Hold</li> <li>Three party</li> <li>Hold</li> <li>Three party</li> </ul>		Explicit call transfer MLPP Explicit call transfer MLPP

• Call data recording

Call data recording			
Call data profile:	<b>•</b>	Price per charge unit:	

• Call data profile

If call data of all subscriber groups and of all subscribers within the groups needs to be stored, you need to select a profile previously created within the call data profiles (see chapter 6.2.4.8). The selected profile is then valid for all subscriber groups and subscribers.

• Price per charge unit

If a profile has been selected, you have the possibility to enter the charge per unit here. The entered value is then valid for all subscriber groups and subscribers. If no call data profile is selected this box remains grey.

• Short code mapping



### Version 1.1 (final Version)

Code		Number		
	Add			
	Edit			
	Remove			

- Short code dialing Enter the short code dialing number here.
- Number Enter the destination telephone number here.

Short code mapping			
Code:	1		
Number:	123456		
	Ok Cancel		

• Number modifications For more details please see <u>chapter 6.2.4.4.1.1</u>.

# 6.2.4.4.2.1 Subscriber group

A subscriber group can be created as follows:

Right-click on "All subscribers" and select "New Subscriber Group":



The following window appears:

Subscrib	er group	$\otimes$
Name:	Group-1	
	Ok Canc	el

Enter a name for the subscriber group and press Ok. A second window appears: In this window the created group is shown as sub item of "All subscribers".



### Version 1.1 (final Version)

<ul> <li>Trunk groups</li> </ul>	Allowed Destinations				
SIP-CM	Name	Тур	e	Number/Prefix	Remove Prefix
Group-1					
Line groups					
ALCR					
	Allowed Sources				
	Туре	Name			
-					
	Permissions				
	Short Code Dialing	Ocall Forwarding	😍 Hold	<	Explicit call transfer
	😍 Call take over	Advice of charge	🔇 Three party	(	MLPP

• Permissions

The green arrow pointing downwards 🙆 in the section permission means, that all the settings in the upper instances within the configuration have been adopted. A green tick 🖉 in the permission box means, that the setting is only active here. A white cross on red 🙆 tells you, that the corresponding permission is deactivated.

Call data recording

Call data recording			
Call data profile:	*	Price per charge unit:	

• Call data profile

If call data of the subscriber group or of the subscribers within the group needs to be saved, a profile previously created in the call data profiles (<u>see chapter 6.2.4.8</u>) is selected. The selected profile is then valid for the subscriber group and for all subscribes within. Values from higher instances are replaced.

- Price per charge unit If a profile has been selected you have the possibility to enter a price per charge unit here. The entered value is valid for the subscriber group and the subscribers. Values from higher instances are replaced.
- Short code mapping



### Version 1.1 (final Version)

ode	Number	
	Add	
	Edit	
	Remove	

Short code dialing

Enter the short code dialing number here.

• Number Enter the destination telephone number here.

Short code	mapping	
Code:	1	
Number:	123456	
	Ok Cancel	

If values are entered these are valid for the subscriber group and the subscribers. Values from higher instances are replaced.

• Number modifications Is described more detailed under trunk groups (<u>see chapter 6.2.4.4.1.1</u>)

If values are entered these are valid for subscriber group and subscribers. Values from higher instances are replaced.

# 6.2.4.4.2.1.1 Creating a Subscriber

You can now set up an ISDN/ANA or SIP subscriber under subscriber group 1. First we will describe how to set up an ISDN/ANA subscriber. How to set up a SIP subscriber is described afterwards.

Please proceed as follows:

Right-click onto "Group-1" and then select "New ISDN/ANA Subscriber" from the menu.

All subs	cribers
Grou	New ISDN/ANA Subscriber
Line gr	New SIP Subscriber
ALCR	Remove

The following window appears:

Subscriber (8	3	Subscriber	$\otimes$
Name:		Name: ISDN Subscriber 1	
Ok Cancel		Ok Cancel	

Please enter a name for the subscriber here. After pressing button "Ok" a further window will appear.





The created subscriber is then listed under "Group-1". When setting up an ISDN or analogue subscriber there is no difference apart of the interface type. In order to make further adjustments to the subscriber settings, click onto the created subscriber. The following window opens:

	Ту	pe	Number/Prefix	Remove Prefix
lowed Sources				
Туре	Name			
rmissions )				
irmissions	Call Forwarding	Hold		Explicit call transfer
rmissions ) Short Code Dialing ) Call take over	Call Forwarding	Hold	y (	Explicit call transfer

• Permissions

The green arrow pointing downwards 🙆 in the section permission means, that all the settings in the upper instances within the configuration have been adopted. A green tick 🖉 in the permission box means, that the setting is only active here. A white cross on red 📀 tells you, that the corresponding permission is deactivated.

- Call data recording
  - Call data profile

If you wish to save call data for the subscriber you need to select a profile created in call data profiles previously (see chapter 6.2.4.8).

• Price per charge unit

If a profile has been selected, you have the possibility to etner the price per charge unit here. The entered value is then valid for all subscriber groups and subscriber. Values from a higher instance are replaced.



Code	Number	
Number modifications		
latch	Action	
atch	Action	

Short code mapping

• Short code dialling

Enter the short code dialling number here.

• Number Enter the destination telephone number here.

If values are entered these are valid for the corresponding subscriber group and subscriber. Values from higher instances are replaced.

• Number modifications For more details please (see chapter 6.2.4.4.1.1)

If values are entered these are valid for the corresponding subscriber group and subscriber. Values from higher configurational instances are replaced.

Following definitions can be made in the next window:

Number:	6789123	Description:	
Interface:	Slot 1 (CCU4) Subm. 1 (SO	 Call take over group:	Ŧ

• Number

Enter the subscriber number.

- Description
   You can enter a (unambiguous) description of the subscriber (name, department, etc.) in this row.
- Interface

Select a dedicated interface for the subscriber with the button.



# • Call take over group

Select the call take over group of subscribers. The appropriate group must have been created in the call take over groups (see chapter 6.2.4.5).

Device options

Device:	Phone	*	Sub:			LLC:		
			BC:	User defined	*	HLC:	User defined	
AOC encoding:	Currency	Ŧ						

Device

Select the type of device connected to the chosen interface above. Available choices are phone, facsimile, modem or a combined device.

• Sub

The additional addressing possibility may be used as additional terminals after the ISDN subscribers interface to be addressed, such as the activation of an amplifier for an announcement or to start a computer program.

The maximum length of sub addresses is 42 digits.

• LLC

Enter here the individual low layer compatibility IE. The maximum length of the low layer compatibility IE is 22 digits.

• BC

Defines the mandatory bearer capability for this subscriber. You can choose between pre-defined profiles or, if you wish, use the user defined profile to declare an individual bearer capability. The maximum length of the bearer capability IE is 22 numbers.

• HLC

Define here the services used by the subscriber. You can choose between pre-defined profiles or, if you wish, use the user defined profile to declare an individual high layer compatibility IE. The maximum length of the high layer compatibility IE is 6 digits.

- AOC encoding
  - Currency

If AOC information is to be generated by the target, it will be sent as currency.

• Units

If AOC information is to be generated by the target, then it will be sent as units.

Following definitions can be made in the next window:

Display Name:	Max MLPP prec. level:	Ŧ
MLPP access resource non preemtable		



• Display Name

The subscriber name can be included here. This name will be shown if Q.SIG or SIP protocol is used. If the DSS1-protocol is used, this name will be sent to the display IE. Depending on the ISDN telephone used, this name is shown in the display of the telephone set.

- Max MLPP prec. level This box determines the priority of the subscriber.
- MLPP access resource non preemptable If this is selected, this subscriber is not allowed to interrupt the connection. If not checked, pre-emption is always allowed.

All settings of ISDN/ANA subscribers can be edited or removed.

# 6.2.4.4.2.1.2 Creating a SIP Subscriber

Click on "Group-1" in the window shown below. The next appearing window allows the selection of a new SIP subscriber by click.

- All sub	scribers
4 Grou	New ISDN/ANA Subscriber
SI	New SIP Subscriber
IS	Remove

The following window appears:



Enter a subscriber name (here SIP-Sub-1) and confirm with Ok.

All subscribers
Group-1
SIP-Sub-1
ISDN Subscriber 1

The given name appears under "Group-1" in the "All subscribers" tree.

For further settings of the SIP subscriber, just click onto the subscriber (here SIP-Sub-1). The following window appears:



	115	e	Number/Prefix	Remove Prefix
Ilowed Sources				
Туре	Name			
ermissions		<b>O</b> Hold		Devolution coll transfor
ermissions )	Call Forwarding	Hold		Explicit call transfer
ermissions Short Code Dialing Call take over	Call Forwarding	Hold Three party		Explicit call transfer

• Permissions

The green arrow pointing downwards 🕐 in the section permission means, that all the settings in the upper instances within the configuration have been adopted. A green tick 🖉 in the permission box means, that the setting is only active here. A white cross on red 😢 tells you, that the corresponding permission is deactivated.

- Call data recording
  - Call data profile
  - If you wish to save call data for the subscriber you need to select a profile created in call data profiles previously (see chapter 6.2.4.8). The selected profile is then valid for the subscriber. Values from higher instances are replaced.
  - Price per charge unit If a profile has been selected you have here the possibility to enter the price per charge unit. The entered value is then values for all subscriber groups and subscribers. Values from higher instances are replaced.



Short code mapping		
Code	Number	
Number medifications		
Match	Action	

Short code mapping

• Short code dialling

Enter the short code dialling number here.

• Number Enter the destination telephone number here.

If values are entered these are valid for the subscriber group and the subscriber. Values from higher instances are replaced.

Number modifications
 Is described in detail under "Trunk groups" (see chapter 6.2.4.4.1.1)

If values are entered these are valid for the subscriber group and the subscriber. Values from higher instabces are replaced.

The next window enables you to make the following settings:

Number:		Description:		
Call take over group:	-	Display Name:		
Max MLPP prec. level:	Ψ.	MLPP access resource non preemtable		

• Number

Entry of the participant's number

- Description
  - You can enter a (unambiguous) description of the subscriber (name, department, etc.) in this row.
- Call take over group



Selection of the call take over group for the subscriber. The group has to be set up previously in call take over groups (see chapter 6.2.4.5).

• Display Name

The name of the subscriber can be included here. This name will be shown if the Q.SIG or SIP protocol is used. If the DSS1-protocol is used, this name will be sent to the display IE. Depending on the used ISDN telephone, this name will be shown in the display of the telephone set.

- Max MLPP prec. level This field selects the priority of the subscriber.
- MLPP access resource non preemtable

If this is selected, the subscriber is not allowed to interrupt the connection. If not checked, preemption is always allowed.

• T38 settings

# This part will be implemented in a later version.

T38 settings				
Use Fax over IP/T.38				
Start T38 on detection of				
DIS-IP CNG-IP CED-IP CNG-Fax				
Remote behaviour after fax No transport codec reinvite with:	r			
Fallback to audio if remote no T38				

• Use Fax over IP/T.38

Check this option to enable or disable the T.38 functionality.

It is recommended to prioritize the transparent voice codecs higher (for example: pcm-aLaw, pcmuLaw,...) than non-transparent voice codecs to increase the likelihood to send a fax to non T.38-enabled devices.

- DIS-IP
  - Digital Identification Signal (over IP)
- CNG-IP
   Calling tone (over IP)
- CED-IP
- Called Terminal Identication (over IP)
- CNG-Fax

Calling Tone (from own facsimile)

• Remote behavior after fax

If this option is disabled, the system closes the connection after completion of fax-transfer.

By activation of this option, the system depends on the remote side behaviour, i.e. the remote side decides to close or not to close the connection.

• Fallback to audio if remote no T38 If the remote side does not support T.38, normally the T.38 connection would be closed.



After activation of this flag, if the remote side does not support T.38, the system tries to "fall-back" to audio, i.e. the system tries to use a transparent codec (negotiated at the first session establishment) to establish a T.38 connection.

- No transport codec re-invite with If at the initial session establishment no transparent codec was negotiated and the system tries to send a facsimile, you can choose to re-invite with a new negotiated transparent-codec or directly with the T.38 protocol.
- Address settings

Address settings				
URI:				
IP service:	UDP	•		
Correct faulty format Public access Can redirect in LAN				

• URI

The URI, user name or IP address.

IP service
 There are

There are three protocols to choose from, dependant of the type of service required. The three protocols are: UDP, TCP and TLS.

• Correct faulty format

If this option is checked, faulty/incomplete IP addresses will be accepted.

Public access

If this option is checked, public access is allowed

• Can redirect in LAN

If this option is checked, prefer a direct connection within a LAN (answer with 305/reflection if both SIP devices flagged and in LAN).

• Codec negotiation settings

Codec negotiation settings					
Pref. voice codec:	Any (negotiate)	*	Pref. data codec:	Any (negotiate)	*

• Pref. Voice codec/ Pref. data codec

The preferred voice and data codecs to be used for this user. These options can be used to "force" a specific user to use specific codecs contrary to the standard codec negotiation settings.

• Account settings

Account settings			Password:		
SRTP mode:	Do not use	-	RTP timeout:	0	
VoIP port profile voice:		*	VoIP port profile data:		-
Simplified digest	Basic aut	horisation	Disable early media for v	oice	
Disable early media fo	r data				

Account



The account or user name.

Password

The password for the account.

SRTP mode

Here, the encryption mode can be set. Possible values are:

• Do not use

Encryption should not be used for this user.

• Try to use

Encryption should be used for this user as default, however if no encryption capability is available (either on this system, or the called party) the call should be made anyway.

- Must use Encryption must be used by this user. If no encryption capability is available (either on this system, or the called party) the call will not be completed.
- RTP timeout

The time (in milli seconds) used for the SIP packet time encoding.

• VoIP port profile voice/ VoIP port profile data

In this section, the profiles that may have been created in VoIP port profiles, are assigned to the available SIP interfaces and define the default behaviour of the interfaces. If you have not created any port profiles, the standard port profile is automatically assigned to the available interfaces. If you delete a profile that was previously assigned to an interface, the standard profile is automatically re-assigned to the interface(s).

- Simplified digest If this option is checked, simplified digest will be used during the authorisation process.
- Basic authorization If this option is checked, basic authorisation will be used.
- Disable early media for data If this option is checked, the EARLY MEDIA event is sent for data calls. This of course incurs traffic over the RTP stream, which in some cases may not be desirable. If this is the case, the EARLY MEDIA event can be de-activated (checking the option).
- Disable early media for voice

If this option is not checked, the EARLY MEDIA event is sent for voice calls. This of course incurs traffic over the RTP stream, which in some cases may not be desirable. If this is the case, the EARLY MEDIA event can be de-activated (checking the option). The standard setting is activated.

# 6.2.4.4.3 Line groups

A line group enables you to unite individual subscribers into a group under one phone number.

# 6.2.4.4.3.1 New Line Group

In this step a line group is set up. Please proceed as follows: Right-click onto "Line group" and select "New Line Group".



▶ Trunk	groups
▹ All sub	scribers
	New Line Group

### The following window appears:

Line group 🛞	Line group	$\otimes$
Name:	Name: Line-1	
Ok Cancel	Ok Cancel	

Enter a name for the line group and confirm by pressing "Ok".

Þ	Trunk groups
ŀ	All subscribers
A	Line groups
	Line-1

The line group is shown as sub item of "Line groups". To adjust the settings of the newly created line group click onto the line group. The following window opens.

Number:		Alert time:	1	* *	
Type of call:	T	Number presentation:			٣

The following boxes have to be filled in:

Number

If you define a line group, the subscriber telephone numbers that relate to this line group must be entered under the respective dialing tree in the telephone number plan.

• Alert time

Maximum duration of ringing in seconds. A maximum of 119 seconds can be entered. This is because ISDN connections are automatically broken-off after a maximum of 2 minutes (120 seconds).

• Type of call

The following ringing sequence adjustments are possible.

Parallel

All telephones ring at the same time

• Sequential

All telephones ring in order, one after another

• Round-Robin

The telephone that comes after the last one that rang, is the next that will ring

- Number presentation
   This is where you select which telephone number will be displayed on the call recipient's telephone.
- Members
Version 1.1 (final Version)



Add Edit		ubscriber/Number
Add Edit		
Edit	Add	
	Edit	
Remove	Remove	

To add subscribers/numbers to the group, right-click into the window below "Subscriber/Number" and select "Add".

The following window opens:

You have the following choices here:

• Named number

Here you enter the name of the "New Number" under "Trunk groups"-> "Trunk-1" in the box "Named Number".

or	the	se	lection	of
•				•••

Subscriber

Here you enter the name of the subscriber created under "All Subscribers"->"Group-1"->"New ISDN/ANA Subscriber" or "New SIP Subscribe".

Group member		$\otimes$
Туре:	Named number	Ŧ
Named Number:	Handy Hr. Meier	
o	Cancel	

Group member		8
Туре:	Subscriber	
Named Number:	ISDN Subscriber 2	
0	k Cancel	

#### All settings in the line groups can be edited or deleted.

#### 6.2.4.4.4 Adjusting the routing

In this chapter we will adjust the availability of the created trunk groups, subscriber groups, number groups and line groups. These settings are made in the "Allowed destinations" and "Allowed sources" of the trunk group, "All subscribers", the subscriber group and the subscribers. This is done as follows:

Mark ",Tunk-1" under ",Trunk groups".

Drag "All subscribers" into the box "Allowed destinations". It is now secured, that "Trunk-1" can reach all subscribers.

",Trunk-1" is automatically added to the "Allowed sources" of "All subscribers". It is now secured, that all subscribers are available for "Trunk-1".



#### Version 1.1 (final Version)



Picture 1

Picture 2

Picture 1: direct connection from "Trunk-1" to "All subscribers".

Picture 2: Connection from "All subscribers" to "Trunk-1".

In the following pictures further possible settings are shown.

Trunk groups	Allowed Destinations			
Number-1	Name	Туре	Number/Prefix	Remove Prefix
Handy Hr. Meier	<ul> <li>All Subscribers</li> </ul>			
Trunk-2	▹ SUB-CCU	Subscriber Group		
All subscribers	▶ Sub-ULU	Subscriber Group		
Line groups	▶ Sub-CAU	Subscriber Group		
ALCR	Trunk-2	Trunk Group		
		Picture 3		
Call Routing 🛛	Allowed Destinations	Picture 3		
Call Routing 3 Trunk groups / Trunk-1 Number-1	Allowed Destinations	Picture 3	Number/Prefix	Remove Prefix
Call Routing 🕄 Trunk groups 4 Trunk-1 Number-1 Handy Hr. Meier	Allowed Destinations Name Trunk-1	Picture 3	Number/Prefix Default Route	Remove Prefix
Call Routing 3 Trunk groups Trunk-1 Number-1 Handy Hr. Meier Trunk-2	Allowed Destinations Name Trunk-1 - All Subscribers	Picture 3	Number/Prefix Default Route	Remove Prefix
Call Routing 23 Trunk groups Trunk-1 Number-1 Handy Hr. Meier Trunk-2 All subscribers	Allowed Destinations Name Trunk-1 4 All Subscribers + SUB-CCU	Picture 3 Type TrunkGroup Subscriber Group	Number/Prefix Default Route	Remove Prefix
Call Routing 23 Trunk groups Trunk-1 Number-1 Handy Hr. Meier Trunk-2 All subscribers Line groups	Allowed Destinations          Name         Trunk-1         4 All Subscribers         > SUB-CCU         > Sub-ULU	Picture 3 Type TrunkGroup Subscriber Group Subscriber Group	Number/Prefix Default Route	Remove Prefix

Picture 4

Picture 3: Connections from "Tunk-1" to "All subscribers", "Trunk-2" and line group ("Line-1"). The line group ("Line-1") can only be called.

Picture 4: Outgoing connections from "Trunk-2" to "All subscribers" and incoming connections to "Trunk-2" from "Trunk-1" and "All subscribers".



Call Routing					
<ul> <li>Trunk groups</li> <li>Trunk-1</li> </ul>	Allowed Destinations				
Trunk-2	Name		Туре	Number/Prefix	Remove Prefix
<ul> <li>All subscribers</li> <li>SUB-CCU</li> </ul>	Trunk-1		TrunkGroup	Default Route	
Sub-ULU	Trunk- 2		Trunk Group	99	yes
Sub-CAU	Line-1		Line Group	100	
Line groups					
Line-1					
ALCR	Allowed Sources				
	Туре	Name			
	Trunk Group	Trunk-2			
	Trunk Group	Trunk-1			
	All Subscribers	All Subscribers			

Picture 5

Picture 5: Outgoing connections from "All subscribers" to "Trunk-1" (as default route), "All subscribers", "Trunk-2" (with prefix: 99) and line group ("Line-1"), as well as incoming connections from "Trunk-1", "Trunk-2" and "All subscribers".

The settings of "Default route" and "Prefix" of the trunk as well as the number of the line group are made as follows:

Default route

Click onto all subscribers. "Trunk-1" appears in the box "Allowed destinations". Right-click onto "Trunk-1"

and select "Default Route". <u>Remove</u> "Trunk-1" is now marked as default route. All calls to targets not included in the "Allowed destinations" are sent via this default route.

• Prefix

Click onto "Allowed destinations". "Trunk-2" is shown. Right-click "Trunk-2" and select "Edit". The following window appears:

AD trunk	group		$\otimes$
Prefix:	99		
🗹 Ren	iove		
	Ok	Cancel	

Enter a number into the box "Prefix". This number is now set as prefix for this trunk. If the box "Remove" is ticked, the prefix is deleted.

The settings of the number for "Line group (Line-1)" are made as follows:

Click "All subscribers" and "line group (Line-1)" will appear in the box "Allowed destination". Right-click "Line group (Line-1)" and select "Edit". Enter a number in the box, under which this line group can then be reached.

Edit numbe	er		$\otimes$
Number:	100		
	Ok	Cancel	



## 6.2.4.5 Call Take Over Groups

To create a call take over group click onto "Call Take Over Group" and the following window will open: In this window you have the possibility to adjust the group under "Groups" and the "Subscriber/Number", belonging to the group, under "Group members".

all Take Over Gro	ups 🛛		
Groups		 	
Group			
Group members			
Subscriber/Numb	er		

### • Group

In order to set up the group right-click into the window below "Group" and select "Add".

oup	
	Add
	Edit
	Remove

Version 1.1 (final Version)



The following window appears:

Cancel

Enter a name for the group in the box "Group name". Confirm with "Ok".

New group	$\otimes$
Group name: CTO-1	
Ok Cancel	

The newly created group is now shown under "Group".

Groups	)		٦
Group			
CTO-1			

This Group "CTO-1" is then added to the corresponding subscribers under "All subscriber" -> "Group-1".

In the next step the subscribers / numbers, which belong to this group, are set up. Click onto "Subscriber/Number" and then right-click into the window. Select "Add".



		Group member		$\otimes$
The following window opens: Under type you can choose be • Subscriber Here the subscriber crea "Group-1"-> "New ISDN Subscriber" is entered.	tween: ted under "All subscribers" -> /ANA Subscriber" or "New SIP	Type: Subscriber:	Subscriber Ok Cancel	
		Group member		$\otimes$
DB.NAMESMAN30.NT	As of May 5th, 2016	Type: Named Numbe	Named number	· I3

Ok

Cancel

Copyright 2017 NovaTec Kommunikationstechni



or

Named number
 In this case the "Named Number" from "Trunk groups"-> "Trunk-1" -> "New Number" is entered.

The created subscribers / numbers are then shown under "Group members".

#### All settings in the call take over groups can be edited and deleted.

### 6.2.4.6 **Dialling Codes**

Under this point the specific dialling codes for the supplementary services can be configured.

Dialing Codes ≅			
Supplementary Services			
Clear Held Call:	R0	Activate Fwd. Busy Prefix:	*67*
Clear Active Call:	R1	Activate Fwd. Busy Postfix:	#
Hold:	R	Deactivate Fixed Fwd:	#21#
Alternation between Lines:	R2	Deactivate Fwd. No Reply:	#61#
Activate Fixed Call Fwd. Prefix:	*21*	Deactivate Fwd. Busy:	#67#
Activate Fixed Call Fwd. Postfix:	#	Call Pick Up:	*14*
Activate Fwd. No Reply Prefix:	*61*	Short code dial:	*#
Activate Fwd. No Reply Postfix:	#	Activate MLPP Prefix:	*35*
Three Party - START:	R3	Activate MLPP Postfix:	*
Three Party - STOP:	R3	CLIR:	*31#
Transfer:	R4	Fax:	*32#
MCID:	R*84	activate_cw:	*43#
deactivate_cw:	#43#	]	

On analogue subscriber lines all the dialling codes listed above are available. The 'R' represents the flash on analogue lines.

On ISDN subscriber lines only the following dialling codes can be used:

- Activate MLPP Prefix/Postfix
- Call Pick Up
- Abb. Dial

All other supplementary services on ISDN phones can be controlled over the phones soft keys/menu only. Please check the user manual of your phone for further instructions.

All entered dialling codes must be unique.



### 6.2.4.7 Synchronisation

The synchronisation of the systems can be effected via RMCS server or ISDN trunks. How it takes place is defined in the synchronisation priority.

Synchronisation via a RMCS server is set as follows:

Act as a Client or a Server:	None	*		
RMCS Mode:	Round Robin	*		
Priority of synchronisation:				
number@VOIP trunk				

• Act as a Client or a Server

Shows, if the system works as a client or as a server. The "Client" need to be selected here.

RMCS Mode

Shows, if the RMCS-Server is selected as a clock source by the client with the sequential or round robin method. Both methods are possible. With the sequential method, the first server of the list will be selected and the next server will only be selected, if the RMCS call to the first server is not successful. With round robin method, on next try, the next server in the list will be selected until the end of the list has been reached. Then it restarts from the beginning of the list.

- Priority of synchronization This field offers a list of priorities to be selected for the RTP synchronization method within the NovaTec gateway. This selection will also be shown in the "Interface Sync Priority", together with all other synchronization sources.
- number@VOIP trunk

In this field the subscriber number of the RMCS server is entered. The number should also be entered in the CUCM. In order to set up this subscriber number please proceed as follows: Click into the window and then right-click. Select "Add" and the following window appears:

RMCS Server	$\otimes$
VoIP trunk:	•
Number of RMCS server:	
Ok	Cancel

The trunk created under "Telephony" -> "SIP" -> "Trunks" can be selected in the top down menu "VoIP Trunk".

Version 1.1 (final Version)



Number of RMCS server: Enter the calling number of the RMCS Server.

For synchronisation via an ISDN interface proceed as follows:

Click into the window "Set Synchronisation Priority for Interfaces" right-click and select "Add".

lattic	Phoney is this interface activated

The following window opens

Use as clock

If checked, the entered source is used as clock.

• Name

• Priority

Via \_\_\_\_\_ the interface for the synchronisation is selected. The interface should be in slave mode.

Entries for the priority level ranging from 0 to 99 are possible.

Synchronisation Pr	iority		0
Use as clock			
Name:			
Priority: 0	* *		
	Ok	Cancel	

Both synchronisation types can be activated at the same time (RMCS and interface), but it is necessary to differentiate with help of the priority. The lowest value has the highest priority. The priorities should be set as follows:

PRI highest priority

BRI

RMCS

All settings can be edited and deleted.

### 6.2.4.8 Call Data Profiles

Under call data profiles you will find the settings for storage of call data within the system.

If you click onto "Call Data Profiles", two preinstalled profiles are shown.

Version 1.1 (final Version)



Name Profile Save Nothing Profile Save All	Call Data Profiles 🛛
Profile Save Nothing Profile Save All	Name
Profile Save All	Profile Save Nothing
	Profile Save All

These profiles can be used by editing them. To do so, right-click onto a profile and select "edit" from the pop up menu.

The following window appears:

You can enter a new profile name in the box "Name" and activate or deactivate the various options.

- Internal -> Internal Stores the connections between the subscribers of a system.
- Internal -> External Stores the connections from subscriber to trunk.
- External -> Internal Stores the connections from trunk to subscriber.
- External -> External Stores the connections from one trunk to another trunk.
- Dialling The data is saved even if the connection has not passed dialling state.
- Alerting The data is saved if the connection is in calling state.
- Connected The data is stored if the connection has been established.

You can also create new profiles. If you wish to do so, please proceed as follows:

Click into the window "Call Data Profiles" with the right mouse button and select "Add" from the pop up menu.

The following window appears:

Enter a profile name in the box "Name" and activate or deactivate the various options.

- Internal -> Internal Stores the connections between the subscribers of a system.
- Internal -> External Stores the connections from subscriber to trunk.
- External -> Internal Stores the connections from trunk to subscriber.
- External -> External Stores the connections from one trunk to another trunk.
- Dialling

The data is saved even if the connection has not passed dialling state.

- Alerting The data is saved if the connection is in calling state.
- Connected

Call Data Profile	$\otimes$				
Name: Profile Save All					
Internal -> Internal	Internal -> External				
🗹 dialing	🗹 dialing				
✓ alerting	✓ alerting				
✓ connected	connected				
External -> Internal	External -> External				
🗹 dialing	🗹 dialing				
✓ alerting	✓ alerting				
✓ connected	connected				
Ok	Cancel				



Copyright 2017 NovaTec Kommunikationstechnik GmbH

Version 1.1 (final Version)



The data is stored if the connection has been established.

Confirm with "Ok". The new profile is now shown in the list of call data profiles.

Call Data Profiles 🛛
Name
Profile Save Nothing
Profile Save All
CDR-1

All settings within the call data profiles can be changed or removed.

### 6.2.4.9 Channel Permissions

In the window "Channel Permissions" you can block the B-channels of the interfaces in different modes. This works as follows:

Channel Permissions 🛛			
Interface	Channel	Mode	

Right-click into the window "Channel Permissions" and select "ADD".

The following window appears:

• Interface

Choose the corresponding interface via

- Channel Here you can choose the channel to be blocked.
- Channel Permissions (S)
  Interface: ....
  Channel: 
  Mode: Incoming 
  Ok Cancel

• Mode

• Incoming The B-channel is only available for incoming calls.

Going

The B-channel is only available for going calls.

Blocked

The B-channel is not available at all and is completely blocked in both directions.

### Settings in the "Channel Permissions" can be edited or deleted.

### 6.2.4.10 **MLPP**

Multi Level Precedence and Preemption

DB.NAMESMAN30.NT

As of May 5th, 2016

Version 1.1 (final Version)



MLPP is a priority controlled access method. This feature originates in the military communication technology in an interconnection with Cisco Unified Communication Manager. The access of a subscriber to a network resource can be interrupted only by a subscriber with a higher priority.

MLPP 🕅			
Mapping Priority - Dig	its		
Flash Override:	unused	*	
Flash:	unused	*	
Immediate:	unused	*	
Priority:	unused	*	
Routine:	unused	*	
Priority Texts			
Namespace:			
Flash Override:			
Flash:			
Immediate:			
Priority:			
Routine:			

Mapping Priority – Digits

On incoming calls from ISDN or analogue lines the user needs to specify the required priority level by dialling a certain digit (after the MLPP dialling code, also see the dialling codes section). At this point the user can specify which digit is mapped to which priority.

Flash Override --> highest Priority: select the digit representing Flash override priority.

Flash: select the digit representing 'Flash' priority.

Immediate: select the digit representing 'Immediate' priority.

Priority: select the digit representing 'Priority' priority.

Routine --> lowest Priority: select the digit representing 'Routine' priority.

If 'unused' is selected for any of the boxes, the corresponding priority level is not selectable for calls initiated by ISDN or analogue subscribers.

Resource-Priority-Namespace

Entries can be change with the button "Edit". In the field "Resource-Priority-Namespace" enter the same name as used in the CUCM.

#### 6.2.4.11 **ALCR**

The "Advanced Least Cost Router (ALCR)" is a feature to enable an automatic selection of the least priced provider for a certain destination.

Version 1.1 (final Version)



- Telephony
  - Localisation
- VoIP
- ISDN
   Call Routing
   Call Take Over Groups
   Dialing Codes
- Synchronisation
- Call Data Profiles Channel Permissions
- Channel Per MI PP
- Advanced Least Cost Routing Global Options
   Bank Holidays
   Premium Rate Numbers
   Network Service Providers

The following settings are possible:

- Global Options
- Bank holidays
- Premium Rate Numbers
- Network Service Provider

# 6.2.4.12 Global Options

Global Options 83		
Typical call duration (s):		
Currency:		
Standard charge generation	Ψ	

### • Typical call duration

Enter the average duration of your telephone calls in seconds here. The cost basis of individual network providers varies from charging for exact seconds of use to blocks of 60 seconds or above (1/1, 60/60, 240/240). The ALCR module calculates the most cost-effective provider based on the time span you have entered here.

• Currency

This text is inserted into the various currency options within the ALCR module and it's settings.

### • Standard charge generation

The ALCR offers the opportunity to display the charges of an alternative network service provider on your ISDN terminal equipment, regardless of whether a cheaper provider is being used or not. This can be advantageous for the commercial use of telephone connections (e. g. pay phones). To use this function, tick the box "Standard charge generation" and select the desired service network provider.

### 6.2.4.13 Bank holidays



Bank holidays can generally be differentiated into two types:

• Fixed bank holidays

These bank holidays occur on the same date every year (e.g. Christmas). They are marked with a red letter symbol in front of the date. Only the day and month are displayed.

#### • Variable bank holidays

These bank holidays occur each year on a different date (e.g. Easter). They are marked with a blue letter symbol in front of the date. In addition, the date includes the year.

If you wish to add a bank holiday, proceed as follows:

Right-click into the window "Bank Holidays". A menu with the options "Add", "Edit" and "Remove" appears. Select "Add" and enter the relevant holiday.

Data	Bank haliday
	Add Edit Remove Title: Christmas Date: 12/24/2017 ; Annually Ok Cancel
Bank Holidays 🛛	
Date	Bank holiday
24.12.XXXX	Christmas

If you need to edit a bank holiday, please take the following steps:

Right-click onto the bank holiday in the list. A menu with the options "Add", "Edit" and "Remove" appears. Select "Edit" and make the necessary changes. Confirm with O.K.



Version 1.1 (final Version)

24.12 Add Edit Remov	e	ristmas
	Bank holiday	8
	Title: Christmas Date: 12/25/2017	Annually
	Ok C	ancel
Bank Holidays	3	
Date	Ba	nk holiday
25.12.XXXX	Ch	ristmas

If you need to delete a bank holiday, please take the following steps:

Right-click onto the bank holiday in the list. A menu with the options "Add", "Edit" and "Remove" appears. Select "Remove".

Bank Holidays 🛛		
Date		Bank holiday
25.12.XXXX	Add Edit Remove	Christmas
Bank Holidays 🛙		
Date		Bank holiday

### 6.2.4.14 Premium Rate Numbers

Here you can set up premium rate services and call barring that will apply to all network service providers.

Call barred

Access to any telephone number with this dialing code is blocked for all network service providers.



#### • Cut-String:

This dialling code will be deleted from the beginning of numbers being dialled. This prevents the user selecting an expensive network service provider. The ALCR cuts off this manually selected dialling code and replaces it using the cheapest network service provider found in the database

#### • Transparent

The selected telephone number will be routed without any modification. This means, that Least Cost Routing will not apply to this telephone number.

elephone number	De	scription	1	ype of premium rate service
	Premium Rate Nur	nber	×	
	Number: Description: Type of service:	01033 Diallng code for Telekom Transparent Ok Cancel		
mium Rate Numbers 🛛				
ephone number	Descr	iption	Тур	e of premium rate service
33	Dialln	g code for Telekom	TRA	NSPARENT

### 6.2.4.15 Network Service Provider

Before it is possible to select the most favourable provider and his best rates, several parameters have to be entered. It is possible to select the most favourable provider and connection after the following information has been entered:

Following settings have to be made in the provider window:

- Network Service Provider
- Regional charge categories
- Time charge categories
- Assign telephone numbers
- Call baring

#### 6.2.4.15.1 Network Service Provider

Right-click into the window. A menu with "Add", "Edit" and "Remove" opens. Select "Add" and enter the relevant parameter.



Version 1.1 (final Version)

work service provider	Shortform	Dialing	code for network ser Trunk	group	
Ado Edii Rer	l : nove				
Network Ser	vice Provider				$\otimes$
Core data					
NSP name	:				
Shortform	of NSP:				
Dialing co	de for NSP:				
Displa	y NSP dialing code in Te	rmina	l Equipment		
Enable	compulsory routing				
Trunk Gro	up:		-		
NSP type					
NSP type:		*	Initiate charge signal:		-
	Landline			None	1
	Pre-Selection		Ok Cancel	Generate from ALCR	
	Call-by-Call			Take over from trunk line	

Network service provider (NSP) is accessible

• NSP name

Enter an explanatory name for the NSP

- Shortform of NSP: Enter a short form of the above entered name for the NSP
- Dialing code for NSP

Enter the dialing code for the NSP (e.g. 01033). The number will automatically be transferred to the telephone number directory

• Display NSP dialing code in Terminal Equipment:

If this option is activated, the provider selected by the ALCR will be displayed on any terminals connected to the system

• Enable compulsory routing

This setting forces routing via a selected provider

• Dialling attempts

Determines the number of dialling attempts the ALCR will undertake if all lines available with this network service provider are busy. This does not mean that the telephone number you are attempting to reach is engaged. If these dialling attempts are unsuccessful, the ALCR will automatically try the next most cost-effective provider. Please bear in mind that a connection will be slower under these circumstances as each dialling attempt takes time.

• Trunk group

Assigns the NSP to a predefined Trunk group

• NSP type

This option defines the NSP type. Possible settings are:

Landline

The network service provider to be entered is also your telecommunications company. It is therefore not necessary to pre-dial any network service provider dialling code. It is possible to enter more than



one network service provider of this type, but only one provider can be set to network service provider (NSP).

• Pre-selection

All outgoing long distance telephone calls are being routed via this provider. It is possible to enter more than one network service providers of this type, but only one provider can be set to network service provider (NSP).

• Call-by-Call

In this case, access is provided by dialling the code for the network service provider before the telephone number of the recipient of the call.

• Initiate charge signal

This option defines how the accrued connection costs will be transmitted to your PABX system

None

If you do not require the charging signal, choose this option

• Take over from trunk line

If your network service provider provides the charge information, choose this option

• Generate from ALCR If the charge information is not available, the ALCR is able to generate this information from the data that has been entered.

### 6.2.4.15.2 Regional charge categories

In the Regional charge categories window you can enter the charge categories of every network service provider.

To set up a new regional charge category, proceed as follows:

Right-click into column "Region" and select "Add" from the pop up menu. Enter the required region and description and confirm with "Ok".

Regional charge cate	gories Time charge categories Assign telephone numbers Call barring
Region	Description
Add Edit Remove	
	Regional charge category 🛞
	Region: Region 50
	Description: Calls up to 50 km
	Ok Cancel
onal charge categories	Time charge categories Assign telephone numbers Call barring
on	Description
	Calls up to 50 km

Version 1.1 (final Version)



#### Region

The "official" name of the region (for example Region 50)

#### • Description

Enter a description of the region (for example 50 km )

#### 6.2.4.15.3 Time charge categories

In the regional charge categories and time charge categories window every charge will be assigned to its valid time zone. All currently entered charges are listed alphabetically in the window of the appropriate network service provider.

To define the time zones and tariffs, follow the steps below:

Click on the "Time charge categories" and then onto "Add" with the right key of the mouse.

Enter the relevant tariffs and choose the appropriate time zones and confirm with "Ok".

egional charge categoria	Time charge ca	tegony	-		U
Charge rates according t	Add Edit Remove				8
Name: MTWTFSaSu	00:00-00:00	Provider	: Telek	om	
Region: Region 50		1			
<ul> <li>✓ Monday</li> <li>✓ Tuesday</li> <li>✓ Wednesday</li> <li>✓ Thursday</li> <li>✓ Friday</li> <li>✓ Saturday</li> </ul>		Cost Dial: [ Call: [	0 0 ection		
V Sunday		Start		Charged time	
				Add Edit Remove	

#### • Name

Enter the name of the time charge category. This row is provided purely as a comment row for your assistance and will be displayed in the column "Time charge category". We would advise you to use a standard method of description (e.g. Mon-Sun 00–00 Hr) as this will help subsequent sorting. However, entering a time charge category name is not necessary. If no name has been entered, the application automatically processes a time charge category name from the entered charge times

#### • Provider

The short form name of the provider to whom this category is assigned to. This field is not editable

#### Region



All regions that have been entered in this providers "Regional charge category" will appear here. Please select the region that is applicable.

• Date/Weekday

Allocate the day on which the charge is valid. If nothing is entered the charge will be valid on all days.

• Time

Enter the time at which the charge is valid. In case of a single charge level for a full day enter 00:00 for both begin and end. The time information must always be entered with a colon, (e.g. 00:00, 23:00 etc.)

• Cost

The Cost field offers different charging possibilities

• Dial

In cases where the network service provider charges a fixed amount for dialling, enter this charge here

Call

In cases where a fee is charged for a connection even when the called subscriber did not answer, please enter this charge here

• Connection

The actual connection costs should be entered here. To edit or create a connection rate click the corresponding button "Add" and the following dialog will appear

Charge rate	$\otimes$
Time charge category lasts	
forever	
◯ for seconds	
Charged time	
Duration of a unit (s):	
Unit price:	
Ok Cancel	

Now select the start of the conversation option and enter the call duration and the unit price. Then click on Ok. The entry will now be transferred to the list. If the provider changes the charge level after the telephone conversation has been running for a specific length of time, this can also be entered. To proceed, click once again onto "Add" and select the option "Seconds after conversation starts". Enter the call duration after which the charge level changes. Enter the changed charge level as before and confirm with "Ok".

Regional charge categories	Time charge categories	Assign telephone numbers	Call barring
Regional charge categorie	Time charge category		
Region 50	MTWTFSaSu 00:00-00:0	0	

### 6.2.4.15.4 Assign telephone numbers

In this window all numbers will be assigned to specific charge zones of individual network service providers. This means that the same dialling codes can be assigned to network service provider 'A' as a regional zone code and to network service provider 'B' as a long distance zone code. For this reason each dialling code has to be assigned separately to each network service provider.

Version 1.1 (final Version)



Regional charge catego	egional charge categories Time charge ca		Assign telephone numbers	Call barring
Regional charge categ	orie Telephor	ne number		
		Individual Remove	assignment	
Ass	ign Telephone	Numbers	$\otimes$	
Tel	ephone numt	oer: 04		
Re	gion:	Region 50	<b>.</b>	
	[	Ok Can	cel	
	1			
Regional charge catego	ries Time cha	arge categories	Assign telephone numbers	Call barrin
Regional charge categ	orie Telephor	ie number		
Region 50	04			

#### • Telephone number

List of telephone numbers that may be assigned a regional charge category

### • **Regional charge category** Available regional charge categories that may be assigned to a telephone number

### 6.2.4.15.5 Call barring

In the "Call Barring" window you can block individual dialling codes for each network service provider on a provider by provider basis.

Regional charge categorie	Time charge categories	Assign telephone numbers	Call barring
Telephone number			
		Individual assignment	
		Remove	
A	ssign call barring number	$\otimes$	
	lumber: 0700		
	0/00		
	Ok Cano	el	
Regional charge categorie	s Time charge categories	Assign telephone numbers	Call barring
Telephone number			
0700			

Entering a new barred number:



Select the network service provider, then click onto "Individual assignment". Enter the numbers to be blocked and confirm with "Ok".

# 6.3 Targets

In NAMES, the word "target" signifies a NovaTec device which has been added to the database and is to be administered through the application. It can be a target for the "jobs" that NAMES can perform.

The main application element in NAMES is the target list, which is always displayed centrally in the main window. After NAMES has been installed, the target list is empty and has to be populated by the user:

Alerts	Targets Target Groups			
	a.			Get Gateway Log
	News	Add	Deskalara	Get Trace Files
	Name A	Address	Backplane	Manage Call Data Records
				Reset Gateway
				Update Firmware
				Configure
				Create Job Trigger
				Edit Job Triggers
				Schedule New Job
				-

The target list allows you to view, select, create, edit and remove targets.

# 6.3.1 Editing a target

Job Scheduler Active Jobs Processed Jobs Firmware Images

To edit a target, right-click the target entry in the list and select "Edit" from the context menu. The "Edit Target" dialogue is identical to the "Create Target" dialogue, except for the checkbox next to the "Password" field. This checkbox specifies whether the password should be changed; if unchecked, no change will be made to the password. To clear the current password, tick the checkbox and leave the password field empty.

# 6.3.2 Removing a target

To remove a target, right-click the entry in the list and select "Delete" from the context menu. It may not be possible to remove a target, for example if running or waiting jobs still exist. A confirmation dialogue will be shown before the target is deleted.

# 6.3.3 Multiple target actions

Both the "Edit" and "Delete" actions may be applied to multiple targets at a time. Simply select multiple targets from the list by holding the Ctrl button on your keyboard to select individual targets or the Shift button to select a range. Right-click the selection and select "Delete" or "MultiEdit" from the context menu.

The "Edit multiple targets" dialogue differs from the "Edit Target" dialogue, as it only contains items that can be set for multiple targets at the same time: login name, location, password and SSL context.



Edit multiple Targets		$\otimes$
		_
Login	TECHNIK	
Location		
Password		
Confirm		
SSL Context	no context assigned	•
Ok	Cano	cel

As with the password in the regular "Edit Target" dialogue, the checkbox corresponding to a field in the "Edit multiple targets" dialogue must be ticked if changes are to be made. For example, to clear the "Location" value on all selected targets, tick the checkbox next to the "Location" field and leave the input box empty.

# 6.3.4 Target details

To show the "Target Details" dialogue for a target, double-click its entry in the list. In addition to information that can be configured in the "Target Edit" dialogue, this window also displays whether a password is configured for this device (but not the actual password – that is never sent to the web client), which configuration was last transmitted to the device and whether any jobs are currently scheduled for the target:

Target Details		$\otimes$
Name	1F5050-246-1423-R2D	
Address	192.168.24.3:800	
Backplane ID	000000C0E15	
CCU Serial Number	1F5050-246-1423-R2D	
Login	TECHNIK	
Location		
Password Protected	NO	
SSL Context	No context assigned	
Scheduled jobs	No scheduled jobs found for this target	
	Close	

This dialogue does not have any edit functions and is for informational purposes only.

# 6.4 Target groups

Targets can be collected in target groups. This makes tasks such as creating a job for an entire group of targets much easier. Target groups are administered through the "Target Groups" tab of the main UI window, which will switch the target list to a target group list.



# 6.4.1 Creating a target group

To create a target group, right-click in the target group list and select "Create" from the context menu. The "Create TargetGroup" dialogue is displayed:

Create TargetGro	pup			$\otimes$
Name	Target Group 1			
Name		Address	Backplane	
		No targets in list		
	Ok	NO largets III list	Cancel	
	OK		Cancer	

You have to enter a name for the target group. You may add targets to the group (see section 6.4.2) now, or leave it empty and add them later. Click "OK" to finish creating the group.

# 6.4.2 Editing a target group

Editing a target group allows you to change the group name or which targets are group members. To edit a target group, right-click the target group in the list and select "Edit" from the context menu. The "Edit TargetGroup" dialogue is displayed, which is identical to the "Create TargetGroup" dialogue.

### 6.4.2.1 Adding Targets

To add targets to a target group, switch back to the "Targets" tab of the main window with the "Edit TargetGroup" window still open. Select the targets you wish to include from the target list and drag them over to the list in the "Edit TargetGroup" dialogue:



٩	Edit TargetGrou	ιp			$\otimes$
Name	Name	Group 1			
Target 1	Name		Address	Backplane	1
Target 2	$\rightarrow$				1
Target 3					
Target 3					
Target 3					
Target 3					
Target 3			No taroets in list		
Target 3		Ok	No targets in list	Abbrechen	

## 6.4.2.2 **Removing targets**

To remove a target from a target group, right-click it in the list of the "Edit TargetGroup" dialogue and select "Remove from Group" from the context menu.

# 6.4.3 Removing a target group

In order to remove a target group, right-click it in the list and select "Delete" from the context menu.

# 6.5 Jobs

In NAMES any changes made to a target are achieved through a "job". Several different types of jobs exist, allowing a number of different administrative and maintenance tasks to be carried out. Jobs may be created by a user – explicitly by using the "Schedule New Job" function, or implicitly by using other functions from the action bar – or in response to a CallHome event (if a corresponding trigger is configured), and may be executed immediately or scheduled for a specific time.

A limited number of jobs can be run at the same time; the maximum number of simultaneous jobs is configured in the NAMES settings (see section 5.3.1) and may be any number in the range of 1 to 10. If all slots are occupied with running jobs, other jobs that are scheduled to run at this time will be added to a waiting queue and executed as slots become available.

# 6.5.1 Job types

### 6.5.1.1 Upload Firmware

This job type facilitates a firmware update. Firmware has to be uploaded to NAMES (see section 5.9.1) first, which may require additional privileges. After that, firmware upload jobs may be created, which will upload the firmware to the target. The device will then write the new firmware to its flash and automatically restart once all phone connections have been terminated.

### 6.5.1.2 **Reset**

This job type sends a reset signal to the device, which will then restart. The device will be unavailable for both phone and maintenance connections whilst restarting. The length of the restart period depends on the device in use.



### 6.5.1.3 **Download Trace Files**

This job type downloads all current trace files (error diagnostic information) from the device to NAMES. These trace files are stored in the database and may be downloaded from NAMES for analysis at a later point. Default behaviour is to delete the files on the target after download, but this can be disabled.

### 6.5.1.4 **Download Log File**

This job type retrieves the current content of the target device's log and adds it to the database. Log information may later be downloaded from NAMES for analysis by specifying a time range from which logs are to be downloaded. Default behaviour is to clear the targets log after download, but this can be disabled.

### 6.5.1.5 **Download CDRs**

This job type retrieves CDRs (Call Data Records) from the target device and saves them in the database. The CDRs may be downloaded from NAMES for analysis later, for a single device or consolidated through target groups.

### 6.5.1.6 Sign Certificate

This job type retrieves Certificate Signing Requests (CSRs) from the target device and issues corresponding certificates using the internal Certificate Authority (CA). The certificates are then uploaded to the device and the device is restarted to activate the TLS configuration. For this job type to work, the internal CA has to be correctly configured (see section 5.7) and the device has to be configured with TLS active and at least one of the communication channels (Maintenance and SIP) has to be configured to generate a CSR.

# 6.5.2 Job states

All jobs are in one of a number of states. The possible states and their meanings are as follows:

- **Pending:** these jobs have been scheduled for a point of time in the future.
- Waiting: these jobs are due to run, but are waiting for slots to become available.
- **Running:** these jobs are currently being run.
- **Done:** these jobs were completed successfully.
- **Failed:** these jobs encountered an error and could not be completed.
- **Obsolete:** these jobs should have been run during NAMES downtime and have been marked obsolete. They may be reactivated from the "Obsolete Jobs" window.

# 6.5.3 Creating a job

Jobs can be created through various means. They may be created automatically in response to events that have occurred on a target device (see section 6.6), created in response to configuration changes through the "Reconfiguration API", triggered through "refresh" buttons in several UI windows and finally scheduled through the "Schedule Job" dialogue.

This section will address the express scheduling of jobs through the "Schedule Job" dialogue; other ways of creating a job will be addressed at the appropriate point in the manual.

The "Schedule Job" dialogue allows all job types, except for "Upload Configuration", to be scheduled. To open the dialogue, select the target, targets or target group you wish to schedule jobs for and then click the "Schedule New Job" button in the action bar on the right:



Tar	get Gateways	
Name	Address	Backplane
test	1.1.1.1:800	
	1 target in list	
lob Type		
Execution Time/Date	09/16/2014	18:38 <sup>*</sup>
nterval	Once	
Firmware		
Allow Gateway Reset		
Delay Reset		
eave Copy on Gateway		
Ok		Cancel

The target list at the top shows the selected targets and may be further edited by dragging targets from the main window into the list or right-clicking targets and selecting remove.

Select a job type from the drop down menu and select the time you wish the job to be scheduled for. If you select the current time or a time in the past, the job will run immediately. If you wish the job to be repeated periodically, select the appropriate interval from the "Interval" drop down menu.

The remaining options depend on the job type you have selected:

- **Firmware:** for an Upload Firmware job, select the firmware you wish to upload to the target.
- **Delay Reset:** for a Reset job, select whether the reset should be delayed until all phone connections have been terminated.
- Leave Copy on Gateway: for all download jobs, select whether the job should leave a copy of the data on the target or remove it. Warning: Using this option with log downloads will cause duplicate log entries in the NAMES database if the device log is not otherwise cleared, as NAMES cannot reliably detect duplicate log entries at the moment.

After selecting the options you wish to use, click "OK" to schedule the job.

# 6.5.4 Viewing and modifying scheduled jobs

Once a job has been scheduled and is in pending state, it will appear in the "Job Scheduler" window, which can be reached through the "Gateway Management" menu and by default through the quick bar:



ob Scheduler			
۹	Exact match	🝸 Job Type	🝸 Job Interval
ExecutionTime -	JobType	Target	Interval
	Edit		Unce
	Close	e	

Jobs can be deleted or edited by right-clicking on their entry and selecting "Delete" or "Edit" from the context menu as long as they are in the pending state. Once their execution time has arrived and they progress to waiting or running, they can no longer be deleted or edited.

Job types cannot be changed after creation, as this is viewed as an entirely different job. If you wish to do this, simply delete the job and recreate it with the required type.

# 6.5.5 Active jobs

The currently running jobs may be viewed by opening the "Active Jobs" window, reachable from the "Gateway Management" menu or through the quick bar. The current job activity state (connecting, uploading, downloading, working...) is displayed. If the job is uploading data to the target, a progress bar for the upload is also displayed.

# 6.5.6 Completed and failed jobs

Completed and failed jobs can be viewed in the "Processed Jobs" window. In addition, a message will be displayed in the notification area to the left of the target list whenever a job fails.

Double-clicking a job in the notification area or the list in the "Processed Jobs" window will open a window showing information about the job, including a failure message that indicates why the job could not be completed.

Jobs may be deleted by right-clicking them in the "Processed Jobs" window and selecting "Delete" from the context menu.



# 6.6 Job Trigger

Job Trigger may be used to automate certain maintenance tasks. The jobs are automatically created and queued by NAMES when a specific event occurs. The association of an event with a job template is referred to as a "Job Trigger" in NAMES.

The following event types may be used to trigger a job:

- **CDR full:** target system storage for CDRs has reached 50% fill level.
- Trace full: the maximum amount of trace files have been stored on the target system.
- Log full: target system storage for logs has reached 100% fill level.
- **Systemstart normal:** the target system has finished booting.
- **TLS has default time:** TLS is configured, but system time is not set.
- Free RAM threshold: the amount of free RAM has fallen below the configured threshold.

Any of these events may be used to trigger any of the following jobs, although the default job type for each event is usually the only useful combination:

- Download CDR's
- Download trace files
- Download log file
- Reset
- Sign certificates

# 6.6.1 Creating a Job trigger

Job triggers may be created either for a single target or for a target group. Creating a Job trigger for a target group will result in creation of Job triggers for each of the targets in the group. Select the target or target group you wish to create a trigger for from the target or target group list, then click the "Create Job Trigger" button in the action bar. The "Create Job Trigger" dialogue is displayed:

Create Job Trigger		$\otimes$
Trigger	CDR full •	
Јор Туре	Download CDRs 🔻	
Disable TLS		
Leave Copy on Gateway		
Reset if necessary	$\checkmark$	
Immediate reset (don't wait for calls)		
Ok	Cancel	

Start by selecting the event type you wish to trigger the job from the "Trigger" combo box. When selecting an event type, the default corresponding job type is automatically selected for you. If you wish a different job type to be triggered, change the selection in the "Job Type" combo box. Finally, configure the job parameters that are available for the selected job type, and click "OK".



# 6.6.2 Edit Job triggers

To edit Job triggers, select the target or target group you wish to edit Job settings for from the target or target group list and then click the "Edit Job Triggers" button in the action bar to the right. The "Job Trigger Management" window is displayed:

Job Trigger Management			$\otimes$
Target Filter	ℤ TargetGroup	ıp Filter	🍸 Job Type 🍸 Trigger 📑 Exit
Target	Trigger	Job	Option
1F5050-017-1235-R2D	CDR full 🔻	Download CDRs 🔹	Leave Copy on Gateway: OFF

To edit a single entry, select the appropriate settings through the combo boxes.

To remove a trigger, right-click the trigger and select "Delete" from the context menu.

The window also offers a "MultiEdit" function which may be used to alter settings for multiple CallHome triggers at once. This is most useful when editing triggers for a target group. To use this function, select multiple CallHome triggers by holding the Ctrl button to add individual entries to your selection or the Shift button to add a range of entries to your selection. Right-click the selection and select "MultiEdit" from the context menu. The "MultiEdit CallHome Triggers" dialogue is displayed, which is functionally identical to the "Create CallHome Trigger" dialogue.

# 6.7 User settings

User settings are available through the "Profile" menu. They allow users to change their password, to select an icon theme that is more appropriate for users suffering from red-green colour blindness or to configure the tool bar located at the bottom of the UI. Currently, icon and tool bar settings are not saved between sessions.

To change the user password, select "My Settings" from the "Profile" menu, then enter a new password into the "Password" input box and confirm it by entering the same password again into the "Confirm" box. Ensure that the checkbox to the right of the "Password" input box is ticked and then click "OK".

The new password must conform to basic password safety rules: it must contain at least five characters, of which at least one must be a lower case letter, one an upper case letter and one a number. If either of these rules are not observed or the password does not match its confirmation, a validation error will be shown and form submission will not be allowed (the "OK" button is disabled).