Firmware
# License Import

Importing the Firmware-license

After opening the database, the following screen will be displayed. It is mandatory to import a valid FW-license into your configuration. A valid license-file can be purchased at NovaTec. After receiving your license from NovaTec, you will be able to configure and set up your NovaTec-System.
The import of the fw-license will be initiated by selecting "Licensing" --> "FW-license..." in the menubar.

A file-dialog appears to let you choose the valid license-file to be imported into the configuration. After succesfully importing the license, an information dialog about the result of this operation will be shown.

Additionally the successful import of a license will be displayed by a check mark at "Licensing" --> "FW-license..." in the menubar.

Attention:
For NTConf it is unpredictable to check the validity of the license-file, i.e. importing a non-valid license-file will leave your system with all ISDN- and VoIP-Interfaces disabled/ inaccessible.

Re-Importing a FW-license from the configuration

If you wish to overwrite the actual license in your configuration, select the entry "FW-license..." at "Licensing" in the menubar.

You will be warned about overwriting your actual license. By confirming this question, a file-dialog appears to let you select a license to be imported and to overwrite the actual license in your configuration.

The successful import of the license-file will be displayed.